

# Quick Start Guide

## Zlinx™ Xtreme Modem

### ZXTxx-RM

## 1 Check for All Required Hardware

- Zlinx™ Xtreme Modem (one of the following models):
  - o ZXT24-RM
  - o ZXT9-RM
- This Quick Start Guide
- CD with Zlinx™ Manager Software and manual
- Antenna
- Mounting ears and hardware
- Additional items required but not included:
  - o 10 – 30 VDC Power Supply
  - o USB Cable
- Conduit mounting accessories sold separately, model ZXT-MT
  - o Cable Gland
  - o Conduit Accessories

## 2 Install Zlinx™ Manager Software

- Insert the CD into your CD ROM Drive. The Zlinx™ Manager Install Wizard should start. Follow the on-screen instructions to install the software.
- If auto run is disabled, locate the **ZlinxMgr.exe** file on the CD-ROM drive and double click to launch it. The Install Wizard should start. Follow the on-screen instructions.

## 3 Install USB Drivers

- Connect the device to the USB port on your PC.
- The “Found New Hardware Wizard” will guide you through the installation process.
- When prompted to connect to Windows Updates to search for drivers, select “No, not at this time” and follow the instructions for installing from the CD or the location on the hard drive.

## 4 Power Connection, TB, & Antenna

- Choose the drivers manually from the CD or the location where Zlinx™ Manager Software is installed.
- When the driver is installed a new COM port labeled “Xtreme” will show up in Windows Device Manager.
- Connect the power supply to the PWR IN +/- terminals on the terminal block.
- Connect the supplied antenna to the RPSMA connector.

**Terminal Block Located Inside Enclosure**

TDA (-)	TDB (+)	RDA (-)	RDB (+)	GND	TD	RD	RTS	CTS	DTR / SLP	GND	FAULT	GND	PWR IN +	PWR IN -
---------	---------	---------	---------	-----	----	----	-----	-----	-----------	-----	-------	-----	----------	----------

**Operating Voltage – 10 to 30 VDC**  
**Maximum Surrounding Ambient Air Temperature - 74°C**  
**See Section 10.**

## 5 Start Zlinx™ Manager Software

- Start the Zlinx™ Manager Software.
- Click on the **Radio Modem** link.
- Click the **Radio Modem Configuration** link.
  - o Select correct COM port and configure it for 9600 baud, Data Bits: 8, Parity: None, Stop Bit: 1.



Figure 3. Communication Parameters Screen

- Click the **Connect** button.
- If the modem is not found, the **Auto Search** button can be used to locate the modem. The auto search will use a sequence of COM Ports and settings until the response is received. If there is still no response, double check the power supply and USB cable. Also, make sure that no other devices are attached wired or wirelessly.



Figure 4. Radio Modem Not Found Screen

- When the software locates the Radio Modem and you click the **OK** button, the **Basic Modem Settings** screen will be displayed.




Figure 5. Radio Modem Found Screen

- ❑ The **Basic Modem Settings** screen will display the Model Number, Function Set Type, Firmware Version, Channel Number, Network Identifier, Destination Address and Baud Rate.



Figure 6. Basic Modem Settings Screen

## 6 Setup the Radio Modem

- ❑ Select a unique Network Identifier. This is especially important if you have other units operating in the same area.
- ❑ Set the Destination Address to FFFF (broadcast) (for ZXT9-RM connecting to Xtreme I/O).
- ❑ If desired, you can change the baud rate and parity on the **Basic Modem Settings** screen. Remember to change your COM port to match.
- ❑ Click the **Update** button to store the settings.
- ❑ Click the **Advanced Modem Settings** tab. Check the Power Level (PL). Select the appropriate power level for your application. For bench testing, PL should be set to 0 and Radio Modems should be separated by at least 1 meter. When using higher power levels, separate the modems by at least 7 meters.
- ❑ If you changed any settings, store them by clicking the **Update** button.

## 7 Set up Your Second Radio Modem

- ❑ Click the **Exit** button. Power off the Radio Modem.
- ❑ Configure your second Radio Modem using the same procedure. Do not proceed to the **RSSI Range Test** step until you have a second modem configured. Two properly configured units are required to proceed to the next step.
- ❑ Configure the second unit with the same settings.

## 8 RSSI Range Test

- ❑ Set the remote modem to Loopback Mode. Loopback connections can be made using the RS-422/485 interface by setting switch 1 and 2 to ON and 3 and 4 to OFF (internal loopback with echo on).

- ❑ On the Radio Modem that is NOT set up for Loopback Mode, run the **RSSI Range Test**. Observe the following indications:
  - The RD, TD and RSSI LEDs will flash as data is sent between the two units.
  - Test results will be displayed on the **RSSI Range Test** screen.

## 9 Configure and Wire to Match Serial Devices

- ❑ Configure serial settings on the Basic Modem Settings tab to match your serial device.
- ❑ Configure the DIP Switch to match your serial device.


RS-232




RS-422



RS-485 4-Wire



RS-485 2-Wire



- ❑ Wiring examples are located in the manual. See Step 4 for TB layout.
- ❑ Terminal Block Signal Direction:
  - RS-232 (Modem is a DCE Device)  
TD – Input, RD – Output, RTS – Input, CTS – Output.
  - RS-422/485 Four Wire  
TDA(-)/TDB(+) – Output, RDA(-)/RDB(+) - Input
  - RS-485 2-Wire - The A(-) and B(+) Signals are tied together by the DIP Switch and are bi-directional.
- ❑ You are now ready for field installation

Sealed Relay Device Information:

Sealed Device: Relay Models G6RL-14-ASI-DC5, G6RL-14-ASI-DC6, G6RL-14-SR-ASI-DC5 or G6RL-14-SR-ASI-DC6 manufactured by Omron Corp.

	Manufacturer	Type
Relay Case and Base	Mitsubishi Engineering Plastics Corp.	5010GN6-30M8AM
Sealant	Three Bond Ltd.	TB2225G

- ❑ Operating Voltage – 10 to 30 VDC
- ❑ **WARNING- SUITABLE FOR USE IN CLASS I, DIVISION 2, GROUPS A, B, C AND D HAZARDOUS LOCATIONS, OR NONHAZARDOUS LOCATIONS ONLY.**
- ❑ **WARNING - EXPLOSION HAZARD - SUBSTITUTION OF ANY COMPONENT MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2.**
- ❑ **WARNING – EXPLOSION HAZARD – WHEN IN HAZARDOUS LOCATIONS, TURN OFF POWER BEFORE REPLACING ANTENNA.**
- ❑ Intended use of equipment – please see the B&B Electronics Data Sheets and Quick Start Guides for each Zlinx Xtreme product for explanations of the intended use of this equipment.
- ❑ Wiring Terminals – Use Copper Wire Only, one conductor per terminal
- ❑ Wire Range 30 – 12 AWG
- ❑ Maximum Surrounding Ambient Air Temperature - 74°C
- ❑ UL Class I, Division 2 wiring methods. The Zlinx Xtreme enclosure is provided with two conduit knockouts that serve as wiring provisions for Class I, Division 2 wiring methods per the National Electrical Code (NEC).

The following instructions include procedures to be followed in order to ensure UL "separation between circuits" as defined in the NEC.

The low-voltage (LV) wiring – DC power, analog & digital signals – must be separated from the high voltage (HV) wiring for the relay contacts. In all cases HV wiring must be rated minimum 250V.

Separation between circuits can be accomplished by using one of the **three** following methods:

- a. Use one conduit knockout to route LV wiring and the second conduit knockout to route the HV wiring, OR see methods 2 and 3 below.  
  
The remaining two methods use one conduit knockout for all wiring. In this case a UL Recognized (UL type QCRV2) conduit plug must be used per the NEC to plug the second conduit knockout.
- b. Enclose LV wiring in a 250V rated insulated sheath to separate it from the HV wiring, OR
- c. Use 250vac rated wires for both LV and HV wiring.

- ❑ Temperature rating of field installed conductors - Field conductors shall be rated 60C/75C minimum (either are acceptable) and sized accordingly.
- ❑ When conduit openings are not being used, a UL Recognized plug (type QCRV2) shall be used.
- ❑ The following is UL-required information regarding the Sealed Relay Devices:

**WARNING** – Exposure to some chemicals may degrade the sealing properties of materials used in the Sealed Relay Device.

**RECOMMENDATION** – It is recommended to inspect the sealed relay device periodically and to check for any degradation of the materials and to replace the component product, not the sealed device, if any degradation is found.