

### **Contact Assembly Instructions**



**NOTE:** This document is representative of all connector positions in this product family.

© 2014 TE Connectivity Ltd. family of companies All Rights Reserved \*Trademark TOOLING ASSISTANCE CENTER 1-800-722-1111 PRODUCT INFORMATION 1-800-522-6752 This controlled document is subject to change. For latest revision and Regional Customer Service, visit our website at www.te.com.

TE Connectivity, TE connectivity (logo), and TE (logo) are trademarks. Other logos, product, and/or company names may be trademarks of their respective owners.



### Contact Disassembly Instructions (Use Extraction Tool 3-1579007-6)



#### CAUTION

DO NOT re-use damaged or worn contacts. Instead, replace them with new contacts and discard the old ones

Pull Out



#### Mating Instructions - with CPA



CPA is locked in Position 1 for shipping and handling before engaging the primary connector latch. CPA can not move forward or backward until the connectors are mated and the primary connector latch "clicks" and engages the interface latch tooth.



# **2** To LOCK CPA After Connector Mate: PUSH CPA forward until an audible "click" is heard.



Finally, push CPA forward to engage secondary lock and ensure proper CPA locking.

## **Unmating Instructions - with CPA**





**2** To UNMATE Connector: With CPA in Position 1, DEPRESS Primary Connector Latch, then simultaneously pull connector/wires while gripping the housing with thumb, index finger, and palm (wire bundle).



#### **REVISION SUMMARY**

Revisions to this instruction include:

- •Updated document to corporate requirements
- New logo