

ENGINEERING SPECIFICATION

INSTALLATION INSTRUCTION SHEETS

1.0 SCOPE

This specification consists of installation instructions for the Self Contained Power Connector for 2-wire cable with ground applications.

2.0 PURPOSE

To define material number system for the above instructions.

- 3.0 REFERENCE MATERIAL NUMBERS See pages 2-3 for the actual instruction sheets. These pages can be used as originals.
- 4.0 DEFINITIONS Not applicable.
- 5.0 PROCEDURES Place one (1) instruction sheet in the smallest unit container.
- 6.0 IMPLEMENTATION December 6, 2005

REVISION:	ECR/ECN INFORMATION:	TITLE: SELF CONTAINED POWER CONNECTOR			SHEET No.	
H <u>EC No:</u> WNA2009-0798 <u>DATE:</u> 2009 / 06 / 03		INSTALLATION INSTRUCTIONS FOR 2 WIRE CABLE WITH GROUND APPLICATIONS			1 of 3	
DOCUMENT NUMBER:		CREATED / REVISED BY:CHECKED BY:APPROVED B		/ED BY:		
SD-19045-002		ETHRODAHL	JMACNEIL JMACNEI		NEIL	
TEMPLATE FILENAME: ENGINEERING_SPEC[SIZE_A](V.1).DOC						

Self Contained Power Connector Installation Instructions For 2 Wire Cable With Ground Applications

The 2-circuit-with-ground connectors will splice non-metallic-sheathed cable in the following wire ranges and types:

Self Contained Connector -

2 Circuit with ground for Solid Wire

Wire Range	Order	Optional	Optional Bench	Optional Bench	Housing	
AWG	AWG No. Hand Tool		Mount Tool	Arbor Press	Color	
10	19403-1300 19285-0084		19285-0088	64006-0200	White	

Self Contained Connector -

2 Circuit with ground for Stranded Wire

Wire Range	Order	Optional	Optional Bench	Optional Bench	Housing	
AWG	No.	Hand Tool	Mount Tool	Arbor Press	Color	
14-16	19403-1011	19403-1011 19285-0074		64006-0200	Blue	
12	19403-1010	19285-0074	N/A	64006-0200	Yellow	
10	19403-1300	19285-0084	19285-0088	64006-0200	White	





Reference Information

UL File Number: E182087, CSA File Number: LR18689-C53 NEC Article: 550, 551, and 545, HUD Section: 3280.801 16 to 12 AWG Version, Current: 20A,Voltage: 600V. 10 AWG Version, 30A, 600V

Installation Procedure:

- 1. Carefully strip and prepare the wires to the configuration as shown in Figure 1.
- 2. Hold the clear strain relief cover with bottom facing upward as shown in Figure 2.
- **3.** Lay wire into locator slots, making sure the black wire is placed into the polarization slot as shown in **Figure 2**.
- 4. Press the cable sheath into the integral strain relief slot as shown in Figure 2. <u>Wires must not</u> extend beyond the stops as shown in Figure 3!
- 5. While holding the strain relief cover, position the housing's hinge posts into the hinge slots and press down until both lock into place as shown in **Figure 3**.
- 6. Close the strain relief cover and housing by hand. Place the connector assembly into Molex tool as shown in **Figure 4.** Squeeze the tool until the connector bottoms out and the locking latches engage on both sides. OR alternately, squeeze the top and bottom closed with tongue and groove pliers as shown in **Figure 4.1**. Pliers must be a minimum of 10" long. Squeeze firmly on both sides, squarely across the connector between ribs A and B to ensure wires seat completely into slots.
- 7. Inspect the connector to ensure the wires have been properly engaged into the housing assembly contacts. A properly terminated wire is fully seated into its proper slots with no significant bow of the cover. If the wires extend past the insulation stops, the wires must be re-terminated with a <u>NEW CONNECTOR</u>. Once the cover has been closed the connector cannot be re-used. Failure to comply with this procedure may result in the failure of the connector.
- 8. Mating and un-mating the completed connector is illustrated in Figure 5.

2 Circuit with ground	d for Round	Stranded Cable
-----------------------	-------------	----------------

Wire Range	Insulation	Order	Optional	Optional Bench	Housing	Cover
AWG	Diameter	Na.	Hand Tool	Arbor Press	Color	Color
14	.340440	19403-1310	19285-0100	64006-0200	White	Clear
14	.600	19403-0011	19285-0100	64006-0200	White	Blue
12	.340440	19421-0001	19285-0100	64006-0200	Yellow	Clear
12	.600	19421-0002	19285-0100	64006-0200	Yellow	Blue





