

ECG 2 click

PID: MIKROE-2507

Weight: 30 g

Condition: New product

Track the patterns of your beating heart with ECG 2 click. ECG 2 click contains ADS1194 16-bit deltasigma analog-to-digital converters from Texas Instruments, a built-in programmable gain amplifier (PGA), an internal reference, and an onboard oscillator.



Table of contents

- 1. Setup guide How to use the ECG 2 click
- 2. MikroPlot application
- 3. Power supply
- 4. OverVoltage and OverCurrent protection
- 5. Application
- 6. Key features

Track the patterns of your beating heart with ECG 2 click. ECG 2 click contains ADS1194 16-bit delta-sigma analog-to-digital converters from Texas Instruments, a built-in programmable gain amplifier (PGA), an internal reference, and an onboard oscillator.

The click communicates with the target MCU over SPI and the following mikroBUS pins: PWM, AN and INT. ECG 2 click runs on 3.3V and 5V power supply.

Note: We offer cables for three electrodes measuring (using 3.5mm jack onboard)

Setup guide – How to use the ECG 2 click

You will need the following things to start recording your ECG:

- 1.ECG 2 click
- 2.Cable
- 3.Disposable adhesive electrode pads (sold in packs of 30)

Of course, you will also need a target board with an MCU (preferably powered from an external battery).

There are two available measuring options:

1. For 3 wire measurement, a 3.5mm jack is used.

You can connect the click to a person using three electrodes placed on the left arm, right arm and the left side of the abdomen (below the heart) or alternatively on the left leg.

We offer cables and electrodes that are marked (left leg (LL) – red, left arm (LA) – black, right arm (RA) – white).

2. For 4 wire measurement, screw terminals are used.

ECG 2 click can also be connected by 4 electrodes that are placed on both arms and legs.

MikroPlot application

MikroPlot is a free data visualization tool (Windows) that can be used to generate an ECG.

The graph is generated from data sent from the MCU (ADC values from ECG click input + time stamp). A UART-USB connection is required.

See the learn.mikroe.com article for more information.

Power supply

ECG 2 click uses both 3.3V and 5V power supply — 3.3V is used as digital power supply and 5V is used for analog power supply (via linear regulator which gives stabilized 3V at output).

OverVoltage and OverCurrent protection

OverVoltage and OverCurrent protection is realized over 22k resistors and diodes.

Application

Measures the electrical activity of a beating heart through electrodes taped to the skin.

DISCLAIMER: ECG 2 click is a prototyping tool, not a medical-grade device. Do not use it to diagnose patients.

Key features

- ADS1194 IC
 - o Built-in oscillator and reference
 - o Built-in programmable gain amplifier
- Onboard 3.5mm jack
- MikroPlot application
- Interface: SPI
- 3.3V and 5V power supply

SPECIFICATION

Product Type	Biomedical
Applications	Measures the electrical activity of a beating heart through electrodes taped to the skin
Key Features	ADS1194 IC, Onboard 3.5mm jack, Mikro Plot application, SPI interface, 3.3V and 5V power supply
Key Benefits	Ready-to-use example and free software tool to generate ECG plot, record ECG while you watch TV, read email, talk over the phone – study patterns to see what excites you (HRV - heart rate variability is a good indicator of state of mind).
Interface	SPI
Power Supply	3.3V and 5V
Click board size	L (57.15 x 25.4 mm)

Pinout diagram

This table shows how the pinout on **ECG 2 click** corresponds to the pinout on the mikroBUSTM socket (the latter shown in the two middle columns).

Notes	Pin	mikroBUS tm				Pin	Notes
Test Pace Out	PAC	1	AN	PWM	16	PWD	Power Down
System reset	RESET	2	RST	INT	15	DRD	Data Ready
SPI chip select	CS	3	CS	RX	14	NC	Not connected
SPI clock	SCLK	4	SCK	ТХ	13	NC	Not connected
SPI data out	DOUT	5	MISO	SCL	12	NC	Not connected
SPI data in	DIN	6	MOSI	SDA	11	NC	Not connected
Power supply	+3.3V	7	3.3V	5V	10	+5V	Power supply
Ground	GND	8	GND	GND	9	GND	Ground

Programming

ECG2 click works best with a battery power supply. In cases where the board is powered through an USB cable, a periodical 50Hz noise will occur on the ECG signal. To counter this noise, the user must place their left hand on the ground pin of their development board.

Code set's up the ECG2 click, measures ECG and sends data to MikroPlot application.

```
01: void main() {
02:
03: uint16_t i = 0;
04: char final_string[20];
05: char time_string[20];
06: double time_value = 0.0;
07: UART0_Init(57600);
08: delay_ms(300);
09:
```

```
10:
     GPIO_Digital_Input(&GPIO_PORTH, _GPIO_PINMASK_0); // pin DRDY is input
     GPIO_Digital_Output(&GPIO_PORTC, _GPIO_PINMASK_4); // pin PWDN is
11:
output
12:
     ECG2_PWDN = 1;
                                                         // ECG2 is powered
ир
    GPIO_Digital_Output(&GPIO_PORTG, _GPIO_PINMASK_0); // pin CS is output
13:
14:
                                                         // deselect ECG2
     ECG2_CS = 1;
click
15:
    GPIO_Digital_Output(&GPIO_PORTE, _GPIO_PINMASK_2); // pin RESET is
output
16:
     ECG2 RESET = 1;
                                                         // pull RESET bit
low for 18 CLK to RESET ECG device
17:
18:
    // init SPI
19:
     SPI0_Init_Advanced(500000, _SPI_MASTER, _SPI_8_BIT | _SPI_CLK_IDLE_LOW
_____SPI_SECOND_CLK_EDGE_TRANSITION, & GPI0_MODULE_SPI0_A245);
     ecq2 hal init();
20:
21:
22:
23:
    // issue RESET pulse
24:
    ECG2\_RESET = 0;
25:
     Delay_us(100);
26:
     ECG2\_RESET = 1;
27:
28:
     Delay ms(1000);
29:
30:
     // device is in RDATAC mode, set it to SDATAC mode to edit registers
     ecq2 hal send command(SDATAC COMMAND);
31:
32:
     delay_ms(1000);
33:
     setup_ecg2();
34:
     while (1)
35:
36:
      {
37:
       while (ECG2_DRDY) {} // Wait for ADS1194 device to prepare output
data. Data is ready every 8 milliseconds
38:
      Delay_us(5);
39:
        for (i = 0; i < num_bytes_sample; i++)</pre>
            ecg_data_sample[i] = SPI_Read(0); // read ADS1194 output data,
40:
one sample
41:
        time_value += 8.0; // increment time value
42:
43:
       // calculate input voltage
       // voltage LA RA
44:
45:
        channel1_voltage = calculate_ecg_channel( ecg_data_sample, 3, Vref,
channel_gain, channel1_voltage_offset );
```

```
// voltage LL RA - channel 2 is usually used for simple ECG
46:
        channel2_voltage = calculate_ecg_channel( ecg_data_sample, 5, Vref,
47:
channel_gain, channel2_voltage_offset );
48:
        sprintf(final_string, "%.2f", channel2_voltage); // convert values to
string and send to MikroPlot
49:
        strcat(final_string, ",");
        sprintf(time_string, "%.2f", time_value);
50:
        strcat(final_string, time_string);
51:
52:
       Uart_Write_Text(final_string);
       Uart_Write_Text("rn");
53:
54:
55:
       // voltage LL LA
56:
        channel3_voltage = calculate_ecg_channel( ecg_data_sample, 7, vref,
channel_gain, channel3_voltage_offset );
        // voltage from temperature sensor
57:
58:
        channel4_voltage = calculate_ecg_channel( ecg_data_sample, 9, vref,
channel_gain, channel4_voltage_offset );
59: }
60: }
```