# ILB IB 24 DI8 DO8

Inline Block IO Module for INTERBUS With Eight Digital Inputs and Eight Digital Outputs

## **AUTOMATIONWORX**

Data Sheet 6892\_en\_04

© PHOENIX CONTACT - 03/2007

## Description

The ILB IB 24 DI8 DO8 module is designed for use within an INTERBUS network. It is used to acquire and output digital signals.

#### **INTERBUS** Features

- Remote bus connection via Inline connector
- Transmission speed 500 kbps
- Diagnostic and status indicators

#### **Input Features**

- Connections for eight digital sensors
- Connection of sensors in 2 and 3-wire technology
- Maximum permissible load current per sensor: 250 mA
- Maximum permissible load current from the sensor supply: 2.0 A
- Diagnostic and status indicators

#### **Output Features**

- Connections for eight digital actuators
- Connection of actuators in 2 and 3-wire technology
- Nominal current per output: 0.5 A
- Total current of all outputs: 4 A
- Short-circuit and overload protected outputs
- Diagnostic and status indicators

<b>I</b> E	_
Ш	
Ш	
ш	
Щ	
1	

Please refer to the "Mounting and Removing Inline Block IO Modules" application note (see "Ordering Data" on page 2).



Make sure you always use the latest documentation. It can be downloaded at <u>www.download.phoenixcontact.com</u>.

A conversion table is available on the Internet at <u>www.download.phoenixcontact.com/general/7000\_en\_00.pdf</u>.





# **Ordering Data**

Description	Туре	Order No.	Pcs./Pkt.
Inline Block IO module for INTERBUS with eight digital inputs and eight digital outputs	ILB IB 24 DI8 DO8	2862372	1
Accessories: Connectors as Replacement Item			
Description	Туре	Order No.	Pcs./Pkt.
Shield connector for INTERBUS connection (color print)	IB IL SCN-6 SHIELD-CP	2863151	5
Connector for the supply (color print)	ILB SCN-12-PWR IN-CP	2863164	10
Connector, with color print, for digital 4-channel or 16-channel Inline output terminals	IB IL SCN-12-OCP	2727624	10
Connector, with color print, for digital 4-channel or 16-channel Inline input terminals	IB IL SCN-12-ICP	2727611	10
Accessories: Other			
Description	Туре	Order No.	Pcs./Pkt.
Recommended end clamp; placed both to the right and left of the module to secure it on the DIN rail	CLIPFIX 35-5	3022276	50
Documentation			
Documentation Description	Туре	Order No.	Pcs./Pkt.
	<b>Type</b> AH ILB INSTALLATION	<b>Order No.</b> 9014931	<b>Pcs./Pkt.</b>
Description			Pcs./Pkt. 1 1

## **Technical Data**

## **General Data**

Housing dimensions with connectors (width x height x depth)

- Weight
- Operating mode
- Transmission speed
- Type of sensor and actuator connection

### **Housing Dimensions**



### Figure 1 Housing dimensions of the module (dimensions in mm)

#### **Ambient Conditions**

Regulations	Developed according to VDE 0160/EN 50178/IEC 62103, UL 508
Ambient temperature (operation)	-25°C to +60°C
Ambient temperature (storage/transport)	-25°C to +85°C
Humidity (operation/storage/transport)	10% to 95% according to EN 61131-2
Air pressure (operation)	80 kPa to 108 kPa (up to 2000 m above sea level)
Air pressure (storage/transport)	66 kPa to 108 kPa (up to 3500 m above sea level)
Degree of protection according to IEC 60529	IP20
Class of protection	Class 3 according to VDE 0106/IEC 60536
Air and creepage distances	According to DIN VDE 0110/IEC 60664, IEC 60664A, DIN VDE 0160/EN 50178/IEC 62103
Housing material	Plastic, PVC-free, PBT, self-extinguishing (V0)
Pollution degree according to EN 60664-1/IEC 60664-1, EN 61131-2/IEC 61131-2	2; condensation not permitted during operation
Surge voltage class	II

95 mm x 55 mm x 141 mm 350 g (with connectors)

Process data mode with 1 byte

500 kbps

2 and 3-wire technology



Electrical Isolation/Isolation of the Voltage Areas		
Test Distance	Test Voltage	
Incoming remote bus / outgoing remote bus	500 V AC, 50 Hz, 1 min	
Incoming remote bus / I/O	500 V AC, 50 Hz, 1 min	
Incoming remote bus / functional earth ground	500 V AC, 50 Hz, 1 min	
Outgoing remote bus / I/O	500 V AC, 50 Hz, 1 min	
Outgoing remote bus / functional earth ground	500 V AC, 50 Hz, 1 min	
I/O / functional earth ground	500 V AC, 50 Hz, 1 min	
Mechanical Requirements		
Vibration test, sinusoidal vibrations according to EN 60068-2-6/IEC 60068-2-6	5g load, 2.5 hours in each space direction	
Shock test according to EN 60068-2-27/IEC 60068-2-27	25g load for 11 ms, half sinusoidal wave, 3 shocks in each space direction and orientation	
Broadband noise according to EN 60068-2-64/IEC 60068-2-64	0.78g load, 2.5 hours in each space direction	

Noise Immunity Test Accord	ing to EN 61000-6-2	
Electrostatic discharge (ESD)	EN 61000-4-2	Criterion B
	IEC 61000-4-2	6 kV contact discharge 8 kV air discharge
Electromagnetic fields	EN 61000-4-3	Criterion A
	IEC 61000-4-3	Field strength: 10 V/m
Fast transients (burst) EN 61000-4-4/ IEC 61000-4-4	Criterion B	
	IEC 61000-4-4	Remote bus: 2 kV Power supply: 2 kV I/O cables: 2 kV
		Criterion A
		All interfaces: 1 kV
Surge voltage	EN 61000-4-5	Criterion B
	IEC 61000-4-5	DC supply lines: ±0.5 kV/±1.0 kV (symmetrical/asymmetrical)
		Signal cables: ±0.5 kV/±0.5 kV (symmetrical/asymmetrical)
Conducted interference	EN 61000-4-6	Criterion A
	IEC 61000-4-6	Test voltage 10 V
Noise Emission Test Accord	ing to EN 61000-6-4	
Noise emission of housing	EN 55022	Class B (residential)
Interface: INTERBUS		
Incoming remote bus		Copper cable (RS-422), connected with Inline shield connector; supply electrically isolated; shielding connected with a capacitor to functional earth ground
Outgoing remote bus		Copper cable (RS-422), connected with Inline shield connector; supply electrically isolated; shielding directly connected to functional earth ground
Recommended cable lengths		See INTERBUS system data in the IBS SYS INTRO G4 UM E user manual

## 24 V Module Supply (Communications Power, Sensor Supply, and Actuator Supply; $\rm U_L, \, U_S,$ and $\rm U_A)$

Nominal value	24 V DC
Tolerance	-15%/+20% according to EN 61131-2
Ripple	±5% according to EN 61131-2
Permissible range	19.2 V to 30.0 V
Current consumption at UL	80 mA
Current consumption at U <sub>S</sub>	2 A
Current consumption at U <sub>A</sub>	4 A
Safety equipment for communications power	Surge protection and protection against polarity reversal
Safety equipment for the sensor supply	Surge, overload and short-circuit protection
Safety equipment for the actuator supply	Surge protection
Connection	Via power connectors
Digital Outputs	
Number	8
Connection method for actuators	2 and 3-wire technology
Nominal output voltage U <sub>OUT</sub>	24 V DC
Differential voltage at Inom	≤1 V
Nominal current I <sub>nom</sub> per channel	0.5 A
Total current	1 x 4 A
Protection	Short-circuit and overload protection
Nominal load	
Ohmic	48 Ω/12 W
Lamp	12 W
Inductive	12 VA (1.2 H, 50 Ω)
Switching frequency with nominal inductive load	0.5 Hz (1.2 H, 50 Ω), maximum
Overload response	Auto restart
Response with inductive overload	Output may be damaged
Reverse voltage protection against short pulses	Protected against reverse voltages
Resistance to permanently applied reverse voltages	Protected against reverse voltages, permissible current 2 A, maximum
Validity of output data after connecting the 24 V supply voltage (power up)	1 ms, typical
Response upon power down	The output follows the supply voltage without delay.
Limitation of the voltage induced on circuit interruption	-30.0 V, approximately
One-time unsolicited energy	1 J, maximum
Protective circuit type	Integrated free running circuit in the output chip
Overcurrent shutdown	0.7 A, minimum
Maximum output current when switched off	10 μΑ



When not loaded, a voltage can be measured even at an output that is not set.

Digital Inputs	
Number	8
Connection method for sensors	2 and 3-wire technology
Input design	According to EN 61131-2 Type 1
Definition of switching thresholds	
Maximum low-level voltage	U <sub>Lmax</sub> < 5 V
Minimum high-level voltage	U <sub>Hmin</sub> > 15 V
Common potentials	Sensor supply U <sub>S</sub> , ground
Nominal input voltage U <sub>IN</sub>	24 V DC
Permissible range	-30 V < U <sub>IN</sub> < +30 V DC
Nominal input current for UIN	5 mA, typical
Current flow	Linear in the range 1 V < $U_{IN}$ < 30 V
Delay time	≤ 500 μs
Permissible cable length to the sensor	100 m
Use of AC sensors	AC sensors in the voltage range < $U_{IN}$ are limited in application

### **Power Dissipation**

Formula to Calculate the Power Dissipation of the Electronics

$P_{TOT} = 1.7 \text{ W} + I_s^2 x \ 0.06 \ \Omega + \sum_{i=1}^{n} (0.1 \text{ W} + I_{Li}^2 x \ 0.28 \ \Omega) + \sum_{j=1}^{m} 0.12 \text{ W} $ $P_{TOT} $ $P_{TOT} $ $Index$ $Vhere$ $P_{TOT} $ $Index$				
nNumber of set outputs (n = 1 to 8)ILiLoad current of the output ijIndexmNumber of set inputs (m = 1 to 8)ISCurrent from the sensor supply	$P_{TOT} = 1.7 \text{ W} + I_s^2 x \ 0.06 \ \Omega + \sum_{i=1}^{n} (0.1 \text{ W} + I_{u_i}^2 x \ 0.28 \ \Omega) + \sum_{j=1}^{m} 0.12 \text{ W}$	$P_{TOT}$ Total power dissipation of the module         i       Index         n       Number of set outputs (n = 1 to 8) $I_{Li}$ Load current of the output i         j       Index         m       Number of set inputs (m = 1 to 8)         Current form the parage supply		

## Limitation of Simultaneity, Derating

No limitation of simultaneity, no derating

## Approvals

For the latest approvals, please visit <u>www.download.phoenixcontact.com</u>.

## Internal Circuit Diagram









# Local Diagnostic and Status Indicators



Figure 3 Diagnostic and status indicators of the ILB IB 24 DI8 DO8 module

Designation	Color	Meaning	
BUS			
UL	Green	Communications power	
RC	Green	Remote bus cable check	
BA	Green	Bus active	
RD	Yellow	Outgoing remote bus disabled	
PWR			
E	Red	Undervoltage sensor supply $U_S$	
US	Green	Sensor supply (connector 6 and	
		connector 7 for sensors)	
UA	Green	Actuator supply (connector 4	
		and connector 5 for actuators)	
OUT			
E	Red	Short circuit or overload at one	
		of the outputs	
1 - 4	Yellow	Status indicators of the outputs	
IN	IN		
E	Red	Short circuit or overload of the	
		sensor supply	
1 - 4	Yellow	Status indicators of the inputs	

If the error LED (E) of the group of eight outputs lights up (connector 4 and connector 5), this indicates that a short circuit or overload is present at one or more of the outputs in this group.



# Connecting INTERBUS, the Supply, Actuators, and Sensors

Figure 4 Terminal point assignment of the connectors

Terminal Point Assignment of INTERBUS Connectors (Connectors 1 and 2 in Figure 4)
---

<b>Terminal P</b>	oint Assignment	Remark/Wire Color in the INTERBUS Standard Cable	
Connector 1 (BUS 1) Incoming Remote Bus			
1.1	DO1	Receive	Green
2.1	DO1	Receive	Yellow
1.2	DI1	Transmit	Pink
2.2	DI1	Transmit	Gray
1.3	F-GND	Reference potential	Brown
2.3			Not used
1.4, 2.4	Shield	Shield potential is connected with a capacitor to functional earth ground (FE) of the potential jumper.	
Connector	2 (BUS 2) Outgoing	Remote Bus	
1.1	DO2	Transmit	Green
2.1	DO2	Transmit	Yellow
1.2	DI2	Receive	Pink
2.2	DI2	Receive	Gray
1.3	R-GND	Reference potential	Brown
2.3			Not used
1.4, 2.4	Shield	Shield potential is connected directly to functional earth ground (FE) of the potential jumper.	

### Terminal Point Assignment of the Power Connector (Connector 3 in Figure 4 on page 9)

Terminal Point	Assignment				
Connector 3 (PWR)					
1.1	24 V sensor supply $U_S$				
2.1	24 V actuator supply U <sub>A</sub>				
1.2, 2.2	24 V communications power $U_L$				
1.3, 2.3	GND				
1.4, 2.4	FE				
1.5, 2.5	24 V communications power $U_L$				
1.6, 2.6	GND				



The terminal points for GND and  $U_L$  can have a total current of 8 A per terminal point. The maximum current carrying capacity of 8 A must not be exceeded.

R

The supply points have the same ground potential. All ground supplies on a module are electrically connected with one another. They are jumpered via the power connector and the module, see "Connection example" on page 11.

# Terminal Point Assignment of Output Connectors (Connectors 4 and 5 in Figure 4 on page 9)

Terminal Point		Assignment
Connector 4 (O1)	Connector 5 (O2)	
1.1, 2.1	1.1, 2.1	Signal output (OUT)
1.2, 2.2	1.2, 2.2	Ground contact (GND) for 2 and 3-wire termination
1.3, 2.3	1.3, 2.3	FE connection for 3-wire termination
1.4, 2.4	1.4, 2.4	Signal output (OUT)
1.5, 2.5	1.5, 2.5	Ground contact (GND) for 2 and 3-wire termination
1.6, 2.6	1.6, 2.6	FE connection for 3-wire termination

### Terminal Point Assignment of Input Connectors (Connectors 6 and 7 in Figure 4 on page 9)

Terminal Point		Assignment
Connector 6 (I1)	Connector 7 (I2)	
1.1, 2.1	1.1, 2.1	Signal input (IN)
1.2, 2.2	1.2, 2.2	Segment voltage U <sub>S</sub> for 2 and 3-wire termination
1.3, 2.3	1.3, 2.3	Ground contact (GND) for 3-wire termination
1.4, 2.4	1.4, 2.4	Signal input (IN)
1.5, 2.5	1.5, 2.5	Segment voltage U <sub>S</sub> for 2 and 3-wire termination
1.6, 2.6	1.6, 2.6	Ground contact (GND) for 3-wire termination

## **Connection Example**



Figure 5 Connection example



The numbers above the module illustration identify the connector slots.

When connecting the actuators and sensors, observe the assignment of the terminal points to the process data (see page 12).

R<sub>2</sub>

The module has an FE spring (metal clip) on the bottom of the electronics base. This spring creates an electrical connection to the DIN rail. Use grounding terminals to connect the DIN rail to protective earth ground. The module is grounded when it is snapped onto the DIN rail.

To ensure reliable functional earth grounding of the module even when the DIN rail is dirty or the metal clip is damaged, Phoenix Contact also recommends grounding the module via one of the FE terminal points.

## **Programming Data**

ID code	03 <sub>hex</sub> (03 <sub>dec</sub> )
Length code	81 <sub>hex</sub>
Process data channel	8 bits
Input address area	1 byte
Output address area	1 byte
Parameter channel (PCP)	0 byte
Register length (bus)	1 byte

## **Process Data**

IБ	
ш	
Ш	
ш	
ш	
ш	
1	

For the assignment of the illustrated (byte.bit) view to your control or computer system, please refer to the DB GB IBS SYS ADDRESS data sheet.

# Assignment of Terminal Points to the OUT Process Data Byte (Slots 4 and 5)

(Byte.bit) Byte		Byte 0							
view	Bit	7	6	5	4	3	2	1	0
Module	Slot		5 (0	D2)		4 (O1)			
	Terminal point (signal)	2.4	1.4	2.1	1.1	2.4	1.4	2.1	1.1
	Terminal point (GND)	2.5	1.5	2.2	1.2	2.5	1.5	2.2	1.2
	Terminal point (FE connection)	2.6	1.6	2.3	1.3	2.6	1.6	2.3	1.3
Status	Slot	5 (O2)			4 (0	O1)			
indicator	LED	4	3	2	1	4	3	2	1

# Assignment of Terminal Points to the IN Process Data Byte (Slots 6 and 7)

(Byte.bit) Byte		Byte 0							
view	Bit	7	6	5	4	3	2	1	0
Module	Slot		7 (	12)		6 (l1)			
	Terminal point (signal)	2.4	1.4	2.1	1.1	2.4	1.4	2.1	1.1
	Terminal point (24 V)	2.5	1.5	2.2	1.2	2.5	1.5	2.2	1.2
	Terminal point (GND)	2.6	1.6	2.3	1.3	2.6	1.6	2.3	1.3
Status	Slot	7 (l2)			6 (	l1)			
indicator	LED	4	3	2	1	4	3	2	1

# Diagnostics

### Error Table With Diagnostic Data and Status Indicators

Error Type	Diagnostic Data	Status Indicators
Sensor voltage U <sub>S</sub> too low	I/O error message	US LED is off E (PWR) LED is red
Short circuit of sensor supply	I/O error message	E (IN) LED of the sensor supply is red
Actuator supply U <sub>A</sub> too low	No response	UA LED is off
Short circuit of a digital output	I/O error message	E (OUT) LED is red

© PHOENIX CONTACT 03/2007