# Ultra-small U-shaped Micro Photoelectric Sensor Amplifier Built-in PM-24 SERIES

panasonic.net/id/pidsx/global

General terms and conditions ...... F-13

Glossary of terms / General precautions ...... P.1455~ / P.1458~

Related Information

LASER SENSORS

FIBER SENSORS

PHOTOELECTRIC SENSORS

MICF

#### AREA SENSORS

LIGHT CURTAINS/ SAFETY COMPONENTS PRESSURE / FLOW SENSORS INDUCTIVE PROXIMITY SENSORS PARTICULAR

SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS WIRE-SAVING SYSTEMS

MEASUREMENT SENSORS STATIC ELECTRICITY PREVENTION DEVICES

> LASER MARKERS

> > PLC

HUMAN MACHINE INTERFACES ENERGY CONSUMPTION VISUALIZATION COMPONENTS

MACHINE VISION SYSTEMS

Se	lection Guide
U-s	haped
Conv	ergent flective

PM-64

PM-24 PM-44/PM-54



saving of your equipment.

Previous



Extremely small size enables space saving!!

# Wide model variety

A wide variety of 5 shapes and 15 models is available. You may select from this wide range to suit the mounting conditions.

Extremely small size and space saving

PM-24 series contributes to the miniaturization or space

# Equipped with two independent outputs

Sensor selection guide...... P.427~

Korea's S-mark..... P.1506

CE

Conforming to EMC Directive

(S)

Certified (Some models only) 211

cognitio

All models are equipped with two independent outputs-Light-ON and Dark-ON.

Hence, one model suffices even if the output is to be used differently, depending upon the location of use. Also, since two independent outputs have been provided, cumbersome handling of the output conversion control input, or fear of logic inversion due to a cable break, is eliminated. The sensor can be connected to the existing wiring as it is.



Note: Ensure to insulate the unused output wire.

# Meets global requirements

Conforms to Europe's EMC Directive and obtains UL Recognition. Both, NPN and PNP output models are available. The **PM-□24** has also obtained Korea's S-mark certification.

SYSTEMS UV CURING SYSTEMS Sensing the starting point on a rotating body

The starting point can be sensed by making a slit in the rotating body.



# ORDER GUIDE

Ту	ре	Appearance (mm in)	Sensing range	Model No. (Note)	Output	Output operation
		R A		PM-K24	NPN open-collector transistor	
	K type	22 6 0.236		PM-K24P	PNP open-collector transistor	
		0.866		PM-K24-R	NPN open-collector transistor	
		N.	PM	PM-L24	NPN open-collector transistor	
	L type	12 0.472		PM-L24P	PNP open-collector transistor	
Ultra-small U type F type		13.4 0.528 0.413	-	PM-L24-R	NPN open-collector transistor	
		10.5 0.413 13.4 0.528 12 0.472		PM-F24	NPN open-collector transistor	
	F type		5 mm 0.197 in (fixed)	PM-F24P	PNP open-collector transistor	Incorporated with 2 outputs: Light-ON / Dark-ON
			PM-F24-R	PM-F24-R	NPN open-collector transistor	
		10.5 0.413 10.5 0.413 0.413 0.9 12 0.472		PM-R24	NPN open-collector transistor	
	R type			PM-R24P	PNP open-collector transistor	
			-	PM-R24-R	NPN open-collector transistor	
		13.4 0.630		PM-U24	NPN open-collector transistor	
	U type			PM-U24P	PNP open-collector transistor	
	13.4 0.528		PM-U24-R	NPN open-collector transistor		

Note: The suffix "-R" indicates a flexible cable type.

#### 3 m 9.843 ft cable length type

3 m 9.843 ft cable length type (standard: 1 m 3.281 ft) is also available. (excluding flexible cable type and PNP output type) When ordering this type, suffix "-C3" to the model No. (e.g.) 3m 9.843 ft cable length type of PM-K24 is "PM-K24-C3".

# **OPTIONS**

Designation	Model No.	Description	Mounting screw • MS-M2
Mounting screw	MS-M2	Mounting screw with washers for the ultra-small type sensor (50 pcs. lot). It can mount securely as it is spring washer attached.	Community of the second s

438

FIBER SENSORS LASER SENSORS

PHOTO-ELECTRIC SENSORS

AREA SENSORS

LIGHT CURTAINS / SAFETY COMPONENTS PRESSURE / FLOW SENSORS

INDUCTIVE PROXIMITY SENSORS

PARTICULAR USE SENSORS

SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS WIRE-SAVING SYSTEMS

MEASURE-MENT SENSORS

STATIC ELECTRICITY PREVENTION DEVICES

LASER MARKERS

PLC

HUMAN MACHINE INTERFACES ENERGY CONSUMPTION VISUALIZATION COMPONENTS

FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

Selection Guide Convergen

PM-64 PM-24

PM-44/ PM-54

FIBER SENSORS

Convergent Reflective

**SPECIFICATIONS** 

LASER SENSORS	$\frown$	Turne	Ultra-	small
PHOTO- ELECTRIC SENSORS		Туре		With flexible cable
MICRO PHOTO-		NPN output	PM-□24	PM-□24-R
ELECTRIC	Item	n See PNP output	PM-□24P	
AREA SENSORS	Sensing range		5 mm 0.19	7 in (fixed)
LIGHT CURTAINS /	Minimum sensing object		0.8 × 1.8 mm 0.031 × 0	0.071 in opaque object
SAFETY COMPONENTS	Hyst	eresis	0.05 mm 0.0	02 in or less
PRESSURE / FLOW SENSORS	Rep	eatability	0.03 mm 0.0	101 in or less
NDUCTIVE	Supp	bly voltage	5 to 24 V DC ±10 % F	Ripple P-P 10 % or less
SENSORS	Curr	ent consumption	15 mA	or less
PARTICULAR USE SENSORS			<npn output="" type=""> NPN open-collector transistor</npn>	<pnp output="" type=""> PNP open-collector transistor</pnp>
SENSOR OPTIONS	Outp	ut	<ul> <li>Maximum sink current: 50 mA</li> <li>Applied voltage: 30 V DC or less (between output and 0 V)</li> <li>Residual voltage: 0.7 V or less (at 50 mA sink current)</li> </ul>	<ul> <li>Maximum source current: 50 mA</li> <li>Applied voltage: 30 V DC or less (between output and + V)</li> <li>Residual voltage: 0.7 V or less (at 50 mA source current)</li> </ul>
SIMPLE WIRE-SAVING UNITS			0.4 V or less (at 16 mA sink current)	0.4 V or less (at 16 mA source current)
WIRE-SAVING SYSTEMS		Utilization category	DC-12 c	or DC-13
MEASURE-		Output operation	Incorporated with 2 outputs: Light-ON / Dark-ON	
SENSORS STATIC ELECTRICITY PREVENTION	s c Response time		Under light received cor Under light interrupted co (Response frequency: 1	condition: 100 µs or less
DEVICES	Operation indicator		Vermilion LED (lights up un	der light received condition)
LASER MARKERS		Pollution degree	3 (Industrial	environment)
PLC	(D)	Ambient temperature (Note 3, 4)	–25 to +55 °C –13 to +131 °F (No dew condensation o	r icing allowed), Storage: –30 to +80 °C –22 to +176 °F
HUMAN	resistance	Ambient humidity	35 to 85 % RH, Stor	rage: 35 to 85 % RH
MACHINE INTERFACES ENERGY	resis	Ambient illuminance	Fluorescent light: 1,000 &	at the light-receiving face
CONSUMPTION VISUALIZATION COMPONENTS		EMC	EN 609	947-5-2
FA	Environmental	Voltage withstandability	1,000 V AC for one min. between all supply	terminals connected together and enclosure
COMPONENTS	invire	Insulation resistance	50 M $\Omega$ , or more, with 250 V DC megger between all	supply terminals connected together and enclosure
MACHINE VISION SYSTEMS	ш	Vibration resistance	10 to 2,000 Hz frequency, 1.5 mm 0.059 in ampl	itude in X, Y and Z directions for two hours each
UV		Shock resistance	15,000 m/s <sup>2</sup> acceleration (1,500 G approx.)	in X, Y and Z directions for three times each
CURING SYSTEMS	Emitting element Material Cable		Infrared LED (Peak emission waveleng	gth: 940 nm 0.037 mil, non-modulated)
			Enclosure: PBT, Slit	cover: Polycarbonate
			0.09 mm <sup>2</sup> 4-core cabtyre cable [PM-□24-R: 0.1 mm <sup>2</sup> flexible, c	bil and heat resistant cabtyre cable (Note 5)], 1 m 3.281 ft long
	Cabl	e extension	Extension up to total 100 m 328.084 ft is	s possible with 0.3 mm <sup>2</sup> , or more, cable.
Selection	on Weight		Net weight:	10 g approx.

2) The response frequency is the value when the disc, given in the figure below, is rotated.







3) In case the PM-24 series is used at an ambient temperature of +50 °C +122 °F, or more, make sure to mount it on a metal body.

4) Take care that the flexibility of the PM-□24-R cable is lost if the ambient temperature in -10 °C +14 °F or less.

5) The cable of PM-124-R is a flexible cable usable on a moving base. When the sensor is mounted on a moving base, fix the sensor cable joint so that stress is not applied to it. (Models other than the PM-D24-R cannot be used on a moving base.)

#### PM-024 PM-024-R





Internal circuit + Users' circuit

Notes: 1) Make sure to connect terminals correctly as the sensor does not incorporate a reverse polarity protection circuit. Further, the output is not incorporated with a short-circuit protection circuit. Do not connect it directly to a power supply or a capacitive load. Faulty wiring may result in damage. 2) Ensure to insulate the unused output wire.

Symbols ... ZD1, ZD2: Surge absorption zener diode Tr1, Tr2 : NPN output transistor

#### PM-D24P

#### I/O circuit diagram



Internal circuit -- Users' circuit

Notes: 1) Make sure to connect terminals correctly as the sensor does not incorporate a reverse polarity protection circuit. Further, the output is not incorporated with a short-circuit protection circuit. Do not connect it directly to a power supply or a capacitive load. Faulty wiring may result in damage. 2) Ensure to insulate the unused output wire.

Symbols ... ZD1, ZD2 : Surge absorption zener diode Tr1, Tr2 : PNP output transistor

# SENSING CHARACTERISTICS (TYPICAL)

#### Sensing position





#### **Output operation**

Wiring diagram

 $\left| \bigcirc \right|$ 

|O|

	Color code	Output operation
Output 1	Black	Light-ON
Output 2	White	Dark-ON

Brown

Black

White

Blue

5 to 24 V DC ±10 %

NPN output type

MENT SENSORS STATIC ELECTRICITY PREVENTION DEVICES

FA COMPONENTS

MACHINE

PLC

#### **Output operation**

	Color code	Output operation	
Output 1	Black	Light-ON	
Output 2	White	Dark-ON	

Load

Load

# VISION SYSTEMS UV CURING SYSTEMS



PM-64
PM-24
PM-44/ PM-54

FIBER SENSORS

LASER SENSORS

PHOTO-ELECTRIC SENSORS

AREA SENSORS

LIGHT CURTAINS / SAFETY COMPONENTS

PRESSURE / FLOW SENSORS

INDUCTIVE PROXIMITY SENSORS

PARTICULAR USE SENSORS

SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS MEASURE-

### Wiring diagram

FIBER SENSORS

# PRECAUTIONS FOR PROPER USE

- Never use this product as a sensing device for personnel protection.
  In case of using sensing devices for
  - personnel protection, use products which
  - meet laws and standards, such as OSHA, ANSI or IEC etc., for personnel protection applicable in each region or country.



Make sure to connect terminals correctly as the sensor does not incorporate a reverse polarity protection circuit. Further, the output is not incorporated with a short-circuit protection circuit. Do not connect

it directly to a power supply or a capacitive load. Faulty wiring may result in damage.

#### Mounting

- When fixing the sensor with screws, use M2 screws and the tightening torque should be 0.15 N⋅m or less.
- Further, use small, round type plain washers. (ø4.3 mm ø0.169 in)

When using the optional mounting screw set **MS-M2**, a spring washer is included.



 In case the PM-24 series is used at an ambient temperature of +50 °C +122 °F, or more, make sure to mount it on a metal body.

#### Refer to p.1458~ for general precautions.

#### Cable extension

• Cable extension is possible up to an overall length of 100 m 328.084 ft with a 0.3 mm<sup>2</sup>, or more, cable. However, since a voltage drop shall occur due to the cable extension, ensure that the power supply voltage at the end of the cable attached to the sensor is within the rating.



But, when the overall cable length, including the cable attached to the sensor, is as given below, there is no need to confirm the voltage.

Conductor cross- section area of extension cable	Total cable length
0.08 to 0.1 mm <sup>2</sup>	Up to 5 m 16.404 ft
0.2 mm <sup>2</sup>	Up to 10 m 32.808 ft
0.3 mm <sup>2</sup>	Up to 20 m 65.617 ft

#### Others

• Since the sensor is intended for use inside machines, no special countermeasures have been taken against extraneous light. Take care that extraneous light is not directly incident on the beam receiving section.



- Do not use during the initial transient time (50 ms) after the power supply is switched on.
- The cable of **PM**-**□24**-**R** is a flexible cable usable on a moving base. When the sensor is mounted on a moving base, fix the sensor cable joint so that stress is not applied to it. (Models other than the **PM**-**□24**-**R** cannot be used on a moving base.)
- Take care that the flexibility of the **PM-□24-R** cable is lost if the ambient temperature is -10 °C +14 °F or less.

PM-64	
PM-24	
PM-44/ PM-54	

FIBER SENSORS

LASER SENSORS

PHOTO-ELECTRIC SENSORS

AREA SENSORS

LIGHT CURTAINS / SAFETY COMPONENTS

PRESSURE / FLOW SENSORS

# DIMENSIONS (Unit: mm in)

The CAD data in the dimensions can be downloaded from our website.



Sensor















-4 0.157

Selection Guide
U-shaped
Convergent Reflective

Р	IVI-64
Ρ	M-24
	M-44/ M-54

-