119

Digital Fiber Sensor **FX-100** SERIES

Related Information

General terms and conditions...... F-7

CE

Conforming to

EMC Directive

LASER SENSORS

FIBER SENSORS



MICRO PHOTOELECTRIC SENSORS

AREA SENSORS LIGHT CURTAINS /

SAFETY COMPONENTS PRESSURE / FLOW SENSORS INDUCTIVE PROXIMITY SENSORS PARTICULAR

USE SENSORS SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS MEASUREMENT SENSORS

STATIC ELECTRICITY PREVENTION DEVICES

> LASER MARKERS

PLC HUMAN MACHINE INTERFACES ENERGY CONSUMPTION VISUALIZATION COMPONENTS

MACHINE VISION SYSTEMS UV CURING SYSTEMS

> Selection Guide

> FX-500

FX-100

FX-300

FX-410

FX-301-F7/ FX-301-F

Fibers

FA COMPONENTS





c(VL)us

Listing

SORS ISOR IONS MPLE VING

> * The **FX-100** series has been changed to Panasonic brand from production in and after July 2011. * Cover opened state is shown.

panasonic.net/id/pidsx/global

Taking fiber sensors to the next level

Good dual digital display

The threshold value and incident light intensity can be both confirmed at the same time, bringing good operability when making changes of each setting.

Panasonic	20 10 3940	FX-100 series
	Threshold value Incide	ent light intensity

Commercially-available connectors reduce lead time and spare part numbers

Compatible with commercially-available connectors, so that processing costs and lead time required for processing after purchase can be greatly reduced. The connection parts same as the **DP-100** series digital pressure sensors and the **PM-64** series micro photoelectric sensors can be commonly used.

Commercially-available crimping connectors are used, so that the processing costs for connection cables can be greatly reduced.





Sensor installation

Saving-space with a width of 9 mm 0.354 in

Very slim body at only 9 mm 0.354 in. This is much thinner than existing fiber sensors. This makes a very large difference when using many units, even if the difference of one unit is small.





Improved stability over long terms

over long periods of time.

Utilizes "Four-chemical emitting element" for light

emission. The light emission is guaranteed to be stable

Simple operation due to clear configuration system

Continued to use the configuration system of digital pressure sensor DP-100 series, which has received high popularity since its release. We have separated the settings into three levels: RUN mode, SET mode, and PRO mode, making operation simpler and easier.



Quick code input function

Simply imputing the default setting "code (number)" will enable sensor settings. Even if the settings are accidentally changed, imputing the code will restore the default settings.

Confirmation can be carried out smoothly via telephone by simply quoting numbers. This can be of great assistance when dealing with foreign country customers.



Panasonic - 02 - 5 - 0 (FX-100 series MODE OFF
Quick setting: Press and wishing simultaneously	y for 2 sec.
Code setting: Press 🔝 and 💟 simultaneously	y for 4 sec.

· Threshold value follow-up cycle

Quick setting numbers (abstract)

	No	Output operation	Timer	Emission amount setting
	-00-	Dark-ON	None	OFF
	-01-	Dark-ON	None	ON
	-66-	Dark-ON	OFF-delay 10 m	s OFF
	-03-	Dark-ON	OFF-delay 10 m	s ON
	- 10-	Light-ON	ON-delay 40 ms	ON
	- 11-	Light-ON	ON-delay 40 ms	OFF
	- 12-	Light-ON	ON-delay 10 ms	ON
	- 13-	Light-ON	ON-delay 10 ms	OFF

Refer to "Quick setting function" and "Code setting function" in "PRECAUTIONS FOR PROPER USE" for details.

FIBER SENSORS

LASER SENSORS

PHOTOELECTRIC SENSORS MICRO

PHOTOELECTRIC SENSORS AREA

SENSORS LIGHT CURTAINS / SAFETY COMPONENTS

PRESSURE / FLOW SENSORS INDUCTIVE PROXIMITY SENSORS

USE SENSORS	
SENSOR OPTIONS	
SIMPLE WIRE-SAVING	

WIRE-SAVING SYSTEMS

MEASUREMENT SENSORS

PREVENTION DEVICES

LASER MARKERS

HUMAN MACHINE ENERGY CONSUMPTION

FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

RUN mode

Selection Guide Fibers

FX-500	
FX-100	
FX-300	
FX-410	
FX-311	
FX-301-F7/ FX-301-F	

Teaching with ON / OFF keys

SET mode

FIBER

LASER SENSORS

PHOTOELECTRIC SENSORS
MICRO PHOTOELECTRIC
SENSORS

Simply press the ON key when an object is present, and OFF when it is not, and teaching is completed. There is no need to consider difference between Light-ON and

Dark-ON.

<Setting example>

Thru-beam type / Retroreflective type



SENSOR

WIRE-SAVING UNITS WIRE-SAVING SYSTEMS MEASUREMENT SENSORS

STATIC ELECTRICITY PREVENTION DEVICES LASER MARKERS

HUMAN MACHINE

ENERGY CONSUMPTION

FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING

SYSTEMS

INTERFACES

VISUALIZATION COMPONENTS

PLC

SIMPLE



Teaching even without an object - Limit teaching function

Threshold value can be set by performing teaching only when an object is absent (when the incident light amount is stable). This is useful when there are other objects in the background also when defecting a minute objects.

Teaching can also be carried out using external input.

Selection Guide Fibers

FX-500
FX-100
FX-300
FX-410
FX-311
FX-301-F7/ FX-301-F

Threshold value follow-up cycle setting function PRO mode

This function performs automatic setting to threshold value by checking the incident light intensity at desired intervals in order to follow the changes in the light amount resulting from changes in the environment over long periods (such as dust). Contributes to reduction in maintenance hours.

* Effective when the output operation is set to Dark-ON, and when using thru-beam type or retroreflective type fibers



Resolves variation in incident light intensity display **GETA** function PRO mode

Even when performing the same sensing operation, there may be variances in the digital values of the fiber amp. There is no problem with the sensor itself, but the operator may find it troubling.

Given value can be corrected with the GETA function, so the apparent variation can be eliminated and the creation of operation manuals can proceed smoothly.



Example of current incident light intensity display of ' 500' is adjusted to '



Emission amount setting function

Emission amount can be reduced in order to achieve stable detection when the receiving light level is saturated, such as detection at close range and detection of transparent or minute objects. Previously, the emission amount level was only one, but from production in December 2007, four level setting (three level + auto setting) has become available. This function brings easier settings than before.

SET mode



Mutual interference is prevented for max. 3 units for standard type **FX-101** \square and max. 4 units in case of long sensing range type **FX-102** \square .

During setting of interference prevention, emitter and output indicator both flash, so it is convenient to confirm which fiber is in the setting process at a glance. Emitter flashes even when an amplifier is not installed close together.

* When the emission frequency is changed, a response time is also changed.



External input setting mode PRO mode

External input can be selected from emission halt, limit teaching / full-auto teaching / 2-level teaching, ECO or emission amount test. Threshold value set at each teaching is also memorized.

* 2-level teaching, emission amount test and threshold value storing setting are available in amplifiers manufactured after December 2007.





Digital display inversion setting

PRO mode

The viewing orientation of the digital display can be inverted in accordance with the setting direction of the amplifier.



When the amount light received approaches the threshold value, the display can be made to blink in order to alert the operator.

<When using at a shift amount of 20% and a threshold value of 1,000> The amount of light received ranges from about 900 to 1,100 when the digital indicator flashes.



Setting copy function to reduce man-hours and human error PRO mode

By connecting a fiber sensor to the master fiber sensor, the master sensor settings can be copied along with data communications. When the same settings are input to several units, trouble from setting errors can be prevented, also changes to the work order will be small when equipment design is changed.





These settings can be copied

Threshold value, output operation, timer operation, timer emission amount, shift, external input, threshold valuestoring, ECO inverting digital display, and threshold value margin

Without mounting bracket

Selectable either mounting on DIN rail or direct mounting with through hole.

Direct mounting brings stability even on a movable parts or installation of a single unit.





ECO.

Available from standard type or long sensing range type

Standard type and long sensing range type are available which has various response time and sensing range. The model best meet application needs can be selected.

Model No.	Туре	Sensing range (FT-43)	Response time
FX-101	Standard type	350 mm 13.780 in	Max. 250 µs
FX-102	Long sensing range type	970 mm 38.189 in	Max. 2.5 ms

Power consumption saving with ECO mode

When there is no key operations in approximately 20 seconds, digital display turns off and power consumption can be reduced to 600mW or less (720mW in normal mode).

	Selection Guide
	Fibers
	Fiber Amplifiers

FX-500
FX-100
FX-300
FX-410
FX-311
FX-301-F7/ FX-301-F

FIBER SENSORS

LASER SENSORS

PHOTOELECTRIC SENSORS MICRO PHOTOELECTRIC SENSORS

AREA SENSORS

LIGHT CURTAINS / SAFETY COMPONENTS PRESSURE / FLOW SENSORS INDUCTIVE PROXIMITY SENSORS

PARTICULAR USE SENSORS

SENSOR OPTIONS	
SIMPLE WIRE-SAVING	

UNITS WIRE-SAVING SYSTEMS

MEASUREMENT

STATIC ELECTRICITY PREVENTION DEVICES

LASER MARKERS

PLC

HUMAN MACHINE INTERFACES

VISUALIZATION COMPONENTS

FA COMPONENTS

MACHINE VISION SYSTEMS

ORDER GUIDE

Amplifiers

27

LASER SENSORS	Amp	lifiers					
PHOTO- ELECTRIC SENSORS	Туре		Appearance	Model No.	Emitting element	Output	• CN-14A-C2
MICRO PHOTO- ELECTRIC SENSORS				FX-101 (Note 2)		NPN open-collector transistor	$\begin{pmatrix} \text{Connector attached} \\ \text{cable 2 m } 6.562 \text{ ft} \end{pmatrix}$
AREA SENSORS		M8 plug-in connector type	-	FX-101-Z (Note 3)		NPN open-collector transistor	* Only include cable set type
LIGHT CURTAINS / SAFETY COMPONENTS	Standard type			FX-101P (Note 2)		PNP open-collector transistor	
PRESSURE / FLOW SENSORS	Standa	M8 plug-in connector type		FX-101P-Z (Note 3)		PNP open-collector transistor	
INDUCTIVE PROXIMITY SENSORS		e set e 1)		FX-101-CC2		NPN open-collector transistor	
PARTICULAR USE SENSORS		Cable (Note	and a ce	FX-101P-CC2		PNP open-collector collector transistor	
SENSOR OPTIONS				FX-102 (Note 2)	Red LED	NPN open-collector transistor	• FC-FX-1 (Protection cover) * It have been attached from the
SIMPLE WIRE-SAVING UNITS	range type	M8 plug-in connector type		FX-102-Z (Note 3)		NPN open-collector transistor	production at July, 2011.
WIRE-SAVING SYSTEMS	g range			FX-102P (Note 2)		PNP open-collector transistor	
MEASURE- MENT SENSORS	sensing I	M8 plug-in connector type		FX-102P-Z (Note 3)		PNP open-collector transistor	
STATIC ELECTRICITY PREVENTION DEVICES	Long :	1)		FX-102-CC2		NPN open-collector transistor	
LASER MARKERS		Cable ((Note		FX-102P-CC2		PNP open-collector transistor	

Notes: 1) The connector attached cable 2 m 6.562 ft CN-14A-C2 is supplied with the amplifier.

2) Make sure to use the optional connector attached cable CN-14A(-R)-Co or the connector CN-14A, or a connector manufactured by J.S.T. Mfg. Co., Ltd. (contact: SPHD-001T-P0.5, housing: PAP-04V-S)

3) Make sure to use the optional M8 connector attached cable CN-24A-C .

OPTIONS

MACHINE VISION SYSTEMS	Designation	Model No.	Description		M8 connector attached cable • CN-24A-C		
		CN-14A-C1	1 m 3.281 ft		→ 31.4 1.236 Ø4 Ø0.157		
UV CURING SYSTEMS	Connector	CN-14A-C2 (Note)	2 m 6.562 ft				
	attached cable	CN-14A-C3	3 m 9.843 ft		Ø9 M8 connector		
		CN-14A-C5	5 m 16.404 ft	0.2 mm ² 4-core cabtyre cable with connector	\ <u>Ø0.354</u> attached cable CN-24A-C□		
		CN-14A-R-C1	1 m 3.281 ft	on one end Cable outer diameter: ø3.7 mm ø0.146 in			
	Connector attached cable	CN-14A-R-C2	2 m 6.562 ft				
Selection Guide	(Flexible type)	CN-14A-R-C3	3 m 9.843 ft		Fixing ring		
Fibers		CN-14A-R-C5	5 m 16.404 ft		Amplifier mounting		
Fiber Amplifiers	M8 connector	CN-24A-C2	2 m 6.562 ft	For M8 plug-in connector type The connector on one end	Amplifier mounting bracket		
	attached cable	CN-24A-C5	5 m 16.404 ft	Cable outer diameter: ø4 mm ø0.157 in	• MS-DIN-4		
FX-500	Connector	CN-14A	Set of 10 housir	ngs and 40 contacts			
FX-100	Amplifier mounting bracket	MS-DIN-4	Mounting brack	et for amplifier			
FX-300		MS-DIN-E	When it moves of	depending on the way it is installed on a DIN rail,			
FX-410	End plates	Two pcs. per set		s ensure that all amplifiers are mounted together fully connected manner.			
FX-311				, ,			
FX-301-F7/ FX-301-F	Note: The connect	tor attached cable CN-	14A-UZ IS SUPPlie	ed with the cable set type FX-10 □ -CC2 .	Connector		

Recommended connector

Contact: SPHD-001T-P0.5, Housing: PAP-04V-S (Manufactured by J.S.T. Mfg. Co., Ltd.) Note: Contact the manufacturer for details of the recommended products.

Recommended crimping tool

Model No.: YC-610R (Manufactured by J.S.T. Mfg. Co., Ltd.) Note: Contact the manufacturer for details of the recommended products.

CN-24A-C 31.4 ø4 ø0.157 8888 Babb ø9 M8 connector ø0.3



nplifier mounting acket **NS-DIN-4**





Housing

Thru-beam type (one pair set)

Fibers are listed in alphabetic order. Refer to p.5~ "Fiber Selection" for details of each fiber.

		(mm in) (Note 1)		Fiber cable		
Model No.	Standard type FX-101		Type / Ambient temperature	length	Dimensions	
FT-140	14,000 551.180	19,600 771.652 (Note 2)	Threaded, M14, Long sensing range, -40 to +70 °C -40 to 158 °F	 ➢ : Free-cut ➢ 10 m 32.808 ft 	P.51	
FT-30	135 5.315	400 15.748	Super quality, Threaded, M3, -55 to +80 °C -67 to 176 °F	2 m 6.562 ft	P.51	
FT-31	130 5.118	340 13.386	Threaded, M3, -55 to +80 °C -67 to 176 °F		P.51	
FT-31S	130 5.118	340 13.386	Sleeve, Threaded, M3, -55 to +80 °C -67 to 176 °F	<mark>≽</mark> 2 m 6.562 ft	P.51	
FT-31W	80 3.150	240 9.449	Threaded, M3, -40 to +60 °C -40 to 140 °F		P.51	
FT-40	320 12.598	870 34.252	Super quality, Threaded, M4, -55 to +80 °C -67 to 176 °F	2 m 6.562 ft	P.51	
FT-42	300 11.811	800 31.496	Threaded, M4, −55 to +80 °C −67 to 176 °F		P.51	
FT-42S	300 11.811	800 31.496	Sleeve, Threaded, M4, -55 to +80 °C -67 to 176 °F	≥ 2 m 6.562 ft	P.51	
FT-42W	260 10.236	720 28.346	Threaded, M4, -40 to +60 °C -40 to 140 °F	2 III 0.302 II	P.51	
FT-43	350 13.780	970 38.189	Threaded, M4, −55 to +80 °C −67 to 176 °F		P.51	
FT-45X	340 13.386	920 36.220	Threaded, M4, −55 to +80 °C −67 to 176 °F	1 m 3.281 ft	P.52	
FT-A11	1,900 74.803	3,600 141.732 (Note 2)	Wide beam, -40 to +70 °C -40 to 158 °F		P.52	
FT-A11W	1,700 66.929	3,400 133.858	Wide beam, -40 to +55 °C -40 to 131 °F		P.52	
FT-A32	3,600 141.732 (Note 2)	3,600 141.732 (Note 2)	Wide beam, -40 to +60 °C -40 to 140 °F	🔀 2 m 6.562 ft	P.52	
T-A32W	3,600 141.732 (Note 2)	3,600 141.732 (Note 2)	Wide beam, -40 to +55 °C -40 to 131 °F		P.52	
FT-AL05	250 9.843	660 25.984	Wide beam, -55 to +80 °C -67 to 176 °F		P.52	
T-E13	6 0.236	19 0.748 Cylindrical, Ultra-small dia., ø3 0.118, -40 to +70 °C -40 to 158 °F		Sc 1 m 2 001 ft	P.52	
T-E23	22 0.866	80 3.150	Cylindrical, Ultra-small dia., ø3 0.118, -40 to +70 °C -40 to 158 °F	<mark>≫</mark> 1 m 3.281 ft	P.52	
FT-H13-FM2	250 9.843	700 27.559	Heat-resistant, -60 to +130 °C -76 to 266 °F	<mark>≫</mark> 2 m 6.562 ft	P.52	
FT-H20-J20-S (Note 3)	135 5.315	420 16.535	Heat-resistant (joint), -60 to +200 °C -76 to 392 °F	200 mm 7.874 in (Note 4)	P.53	
FT-H20-J30-S (Note 3)	135 5.315	420 16.535	Heat-resistant (joint), -60 to +200 °C -76 to 392 °F	300 mm 11.811 in (Note 4)	P.53	
FT-H20-J50-S (Note 3)	135 5.315	420 16.535	Heat-resistant (joint), -60 to +200 °C -76 to 392 °F	500 mm 19.685 in (Note 4)	P.53	
FT-H20-M1	210 8.268	540 21.260	Heat-resistant, -60 to +200 °C -76 to 392 °F	1 m 3.281 ft	P.53	
FT-H20-VJ50-S (Note 3)	150 5.906	500 19.685	Heat-resistant (joint), −60 to +200 °C −76 to 392 °F	3500 mm 19.685 in (Note 4)	P.53	
FT-H20-VJ80-S (Note 3)	150 5.906	500 19.685	Heat-resistant (joint), -60 to +200 °C -76 to 392 °F	300 mm 31.496 in (Note 4)	P.53	
FT-H20W-M1	100 3.937	300 11.811	Heat-resistant, -60 to +200 °C -76 to 392 °F		P.53	
FT-H30-M1V-S (Note 5)	110 4.331	280 11.024	Vacuum-resistant, −30 to +300 °C −22 to 572 °F	1 m 3.281 ft	P.53	
FT-H35-M2	170 6.693	490 19.291	Heat-resistant, -60 to +350 °C -76 to 572 °F	0 m 0 500 f	P.53	
FT-H35-M2S6	170 6.693	490 19.291	Heat-resistant, -60 to +350 °C -76 to 572 °F	2 m 6.562 ft	P.53	
FT-HL80Y	990 38.976	2,340 92.126	Chemical-resistant, Metal-free, -40 to +115 °C -76 to 239 °F	2 m 6.562 ft (Note 6)	P.53	
			-40 10 THO C -/0 10 239 F			

Notes: 1) Note that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut.

2) The fiber cable length practically limits the sensing range.

3) Heat-resistant joint fibers and ordinary-temperature fibers (FT-42) are sold as a set.

4) This is the fiber length (fixed length) for heat-resistant fibers. The ordinary-temperature fibers are free-cut to 2 m 6.562 ft.

5) Sold as a set comprising vacuum type fiber + photo-terminal (FV-BR1) + fiber at atmospheric side (FT-J8).

6) The allowable cutting range is 500 mm 19.685 in from the end that the amplifier inserted.

LASER SENSORS PHOTO-ELECTRIC

Thru-beam type (one pair set)

Fibers are listed in alphabetic order. Refer to p.5~ "Fiber Selection" for details of each fiber.

ELECTRIC	Fibers are listed in alphabetic order. Refer to p.5~ "Fiber Selection" for details of each fiber.								
	Model No.	Sensing range (mm in) (Note 1)	Type / Ambient temperature	Fiber cable length	Dimensions			
MICRO PHOTO- ELECTRIC SENSORS		Standard type FX-101	Long sensing range type FX-102		Free-cut	Dimensions			
AREA SENSORS	FT-KS40	2,200 86.614	3,600 141.732 (Note 2)	Narrow Beam, -40 to +60 °C -40 to 140 °F		P.54			
LIGHT CURTAINS / SAFETY	FT-KV26	135 5.315	560 22.047	Narrow Beam, Side-view, -40 to +60 °C -40 to 140 °F	≥ 2 m 6.562 ft	P.54			
COMPONENTS	FT-KV40	2,200 86.614	3,600 141.732 (Note 2)	Narrow Beam, Side-view, -40 to +60 °C -40 to 140 °F		P.54			
PRESSURE / FLOW SENSORS	FT-KV40W	2,200 86.614	3,600 141.732 (Note 2)	Narrow Beam, Side-view, -40 to +60 °C -40 to 140 °F	≥ 2 m 6.562 ft	P.54			
INDUCTIVE PROXIMITY SENSORS	FT-L80Y	1,100 43.307	2,600 102.362	Chemical-resistant, Metal-free, -40 to +70 °C -40 to 158 °F	2 m 6.562 ft (Note 3)	P.54			
PARTICULAR USE SENSORS	FT-R31	100 3.937	340 13.386	Square head, M3, -55 to +80 °C -67 to 176 °F		P.54			
	FT-R40	270 10.630	740 29.134	Threaded, M4, Elbow, -55 to +80 °C -67 to 176 °F		P.54			
SENSOR	FT-R41W	250 9.843	710 27.953	Square head, M4, -40 to +60 °C -40 to 140 °F		P.54			
SIMPLE WIRE-SAVING UNITS	FT-R42W	510 20.079	2,000 78.740	Square head, M4, -40 to +60 °C -40 to 140 °F	<mark>≫</mark> 2 m 6.562 ft	P.54			
WIRE-SAVING	FT-R43	210 8.268	640 25.197	Square head, M4, -55 to +80 °C -67 to 176 °F		P.54			
SYSTEMS	FT-R44Y	210 8.268	640 25.197	Oil-resistant, Square head, M4, Cable-protection type, -55 to +80 °C -67 to 176 °F		P.55			
MEASURE- MENT SENSORS	FT-R60Y	690 27.165	1,890 74.409	Oil-resistant, Square head, M6, Full-protection type, −55 to +80 °C −67 to 176 °F		P.55			
STATIC ELECTRICITY PREVENTION	FT-S11	40 1.575	90 3.543	Cylindrical, <i>ф</i> 1 0.039, -55 to +80 °C -67 to 176 °F	500 mm 19.685 in	P.55			
LASER MARKERS	FT-S20	135 5.315	400 15.748	Super quality, Cylindrical, <i>φ</i> 1.5 0.059, -55 to +80 °C -67 to 176 °F	2 m 6.562 ft	P.55			
WARKERS	FT-S21	130 5.118	340 13.386	Cylindrical, <i>φ</i> 1.5 0.059, -55 to +80 °C -67 to 176 °F	≥ 2 m 6.562 ft	P.55			
PLC	FT-S21W	80 3.150	240 9.449	Cylindrical, <i>φ</i> 1.5 0.059, -40 to +60 °C -40 to 140 °F	a~ 2 m 0.302 m	P.55			
HUMAN MACHINE INTERFACES	FT-S30	320 12.598	870 34.252	Super quality, Cylindrical, ¢3 0.118, −55 to +80 °C −67 to 176 °F	2 m 6.562 ft	P.55			
ENERGY	FT-S31W	260 10.236	720 28.346	Cylindrical, <i>ϕ</i> 3 0.118, −40 to +60 °C −40 to 140 °F		P.55			
CONSUMPTION VISUALIZATION COMPONENTS	FT-S32	1,100 43.307	3,000 118.110	Cylindrical, <i>φ</i> 2.5 0.098, -40 to +70 °C -40 to 158 °F		P.55			
FA COMPONENTS	FT-V23	160 6.299	400 15.748	Sleeve, Cylindrical, Side-view, φ2 0.079, -55 to +80 °C -67 to 176 °F		P.55			
MACHINE VISION SYSTEMS	FT-V24W	35 1.378	90 3.543	Sleeve, Cylindrical, Side-view, φ2 0.079, -40 to +60 °C -40 to 140 °F	<mark>≫</mark> 2 m 6.562 ft	P.56			
UV CURING SYSTEMS	FT-V25	95 3.740	260 10.236	Sleeve, Cylindrical, Side-view, <i>φ</i> 2 0.079, -55 to +80 °C -67 to 176 °F		P.56			
SYSTEMS	FT-V30	180 7.087	480 18.898	Sleeve, Cylindrical, Side-view, φ2.5 0.098, -55 to +80 °C -67 to 176 °F		P.56			
	FT-V40	1,000 39.370	3,100 122.047	Cylindrical, Side-view, <i>ϕ</i> 4 0.157, -40 to +60 °C -40 to 140 °F		P.56			
	FT-V80Y	340 13.386	800 31.496	Chemical-resistant, Metal-free -40 to +70 °C -40 to 158 °F	2 m 6.562 ft (Note 3)	P.56			
Selection Guide	FT-Z20HBW	100 3.937	320 12.598	Flat with boss, -40 to +60 °C -40 to 140 °F	≥ 1 m 3.281 ft	P.56			
Fibers	FT-Z20W	280 11.024	730 28.740	Flat with boss, -40 to +60 °C -40 to 140 °F	- ∧ 1 III 3.201 It	P.56			
Fiber Amplifiers	FT-Z30	710 27.953	2,300 90.551	Flat, -40 to +60 °C -40 to 140 °F		P.56			
	FT-Z30E	1,200 47.244	3,200 125.984	Flat, -40 to +60 °C -40 to 140 °F		P.56			
FX-500	FT-Z30EW	1,400 55.118	2,600 102.362	Flat, -40 to +60 °C -40 to 140 °F		P.57			
FX-100	FT-Z30H	1,400 55.118	3,200 125.984	Flat, -40 to +60 °C -40 to 140 °F		P.57			
FX-300	FT-Z30HW	1,400 55.118	3,200 125.984	Flat, -40 to +60 °C -40 to 140 °F	<mark>}<</mark> 2 m 6.562 ft	P.57			
FX-410	FT-Z30W	540 21.260	1,800 70.866	Flat, -40 to +60 °C -40 to 140 °F		P.57			
FX-311	FT-Z40HBW	260 10.236	720 28.346	Flat with boss, -40 to +60 °C -40 to 140 °F		P.57			
FX-301-F7/ FX-301-F	FT-Z40W	410 16.142	1,200 47.244	Flat with boss, -40 to +60 °C -40 to 140 °F		P.57			
	FT-Z802Y	520 20.472	3,100 122.047	Chemical-resistant, 0 to +60 °C 32 to 140 °F		P.57			

Notes: 1) Note that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut.
2) The fiber cable length practically limits the sensing range.
3) The allowable cutting range is 500 mm 19.685 in from the end that the amplifier inserted.

Retroreflective type _____ $\overline{}$

Fibers are listed in alphabetic order. Refer to p.5~ "Fiber Selection" for details of each fiber.

Model No.	Sensing range (mm	in) (Note 1) (Note 2)	Type / Ambient temperature	Fiber cable	Dimensions	
woder no.	Standard type FX-101	Long sensing range type FX-102	Type / Ambient temperature	length <mark>≫</mark> : Free-cut	Dimensions	
FR-KZ22E	15 to 200 0.591 to 7.874	15 to 360 0.591 to 14.173	Wafer mapping, -40 to +60 °C -40 to 140 °F		P.58	
FR-KZ50E	20 to 200 0.787 to 7.874	20 to 350 0.787 to 13.780	Narrow Beam, Side sensing, –40 to +60 $^\circ\text{C}$ –40 to 140 $^\circ\text{F}$	≥ 2 m 6.562 ft	P.58	
FR-KZ50H	20 to 200 0.787 to 7.874	20 to 350 0.787 to 13.780			P.58	
FR-Z50HW	100 to 550 3.937 to 21.654	100 to 830 3.937 to 32.677	With polarizing filter, -25 to +55 °C -13 to 131 °F		P.58	

Notes: 1) Note that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut. The sensing range of **FR-KZ22E** is specified for the attached reflector. The sensing range of **FR-KZ50H** is specified for the attached reflector **RF-003**. The sensing range of **FR-Z50HW** is specified for the **RF-13**.

2) The sensing range is the possible setting range for the attached reflector. The fiber can detect an object less than setting range for the reflector. However, note that if there are any white or highly-reflective surfaces near the fiber head, reflected incident light may affect the fiber head. If this occurs, adjust the threshold value of the amplifier unit before use.

Reflective type

Fibers are listed in alphabetic order. Refer to p.5~ "Fiber Selection" for details of each fiber.

	Sensing range (mm in) (Note 1) (Note 2) / Description			Fiber cable		
Model No.			Type / Ambient temperature	length	Dimensions	
Standard type FX-101 Long sensing range type FX-102 FD-30 45 1.772 155 6.102		Current quality. Threaded M2 55 to 100 °C 67 to 176 °C	2 m 6.562 ft	P.59		
			Super quality, Threaded, M3, -55 to +80 °C -67 to 176 °F	2 M 0.502 M		
FD-31	35 1.378	140 5.512	Threaded, M3, -55 to +80 °C -67 to 176 °F		P.59	
FD-31W	15 0.591	60 2.362	Threaded, M3, -40 to +60 °C -40 to 140 °F	<mark>≫</mark> 2 m 6.562 ft	P.59	
FD-32G	70 2.756	190 7.480	Threaded, M3, -55 to +80 °C -67 to 176 °F		P.59	
FD-32GX	75 2.953	210 8.268	Threaded, M3, -55 to +80 °C -67 to 176 °F	3.281 ft (Note 3)	P.59	
FD-40	45 1.772	155 6.102	Super quality, Threaded, M4, -55 to +80 °C -67 to 176 °F	2 m 6.562 ft	P.59	
FD-41	35 1.378	140 5.512	Threaded, M4, -55 to +80 °C -67 to 176 °F		P.59	
FD-41S	35 1.378	140 5.512	Sleeve, Threaded, M4, -55 to +80 °C -67 to 176 °F	-	P.59	
FD-41SW	15 0.591	60 2.362	Sleeve, Threaded, M4, -40 to +60 °C -40 to 140 °F	2 m 6.562 ft	P.59	
FD-41W	80 3.150	230 9.055	Threaded, M4, -40 to +60 °C -40 to 140 °F		P.59	
FD-42G	70 2.756	190 7.480	Threaded, M4, -55 to +80 °C -67 to 176 °F		P.60	
FD-42GW	45 1.772	140 5.512	Threaded, M4, -40 to +60 °C -40 to 140 °F		P.60	
FD-60	140 5.512	420 16.535	Super quality, Threaded, M6, -55 to +80 °C -67 to 176 °F	2 m 6.562 ft	P.60	
FD-61	120 4.724	410 16.142	Threaded, M6, -55 to +80 °C -67 to 176 °F		P.60	
FD-61G	120 4.724	350 13.780	Threaded, M6, -55 to +80 °C -67 to 176 °F		P.60	
FD-61S	130 5.118	360 14.173	Sleeve, Threaded, M6, -55 to +80 °C -67 to 176 °F	<mark>≫</mark> 2 m 6.562 ft	P.60	
FD-61W	80 3.150	230 9.055	Threaded, M6, -40 to +60 °C -40 to 140 °F		P.60	
FD-62	170 6.693	450 17.717	Threaded, M6, -55 to +80 °C -67 to 176 °F		P.60	
FD-64X	75 2.953	220 8.661	Threaded, M6, -55 to +80 °C -67 to 176 °F	1 m 3.281 ft	P.61	
FD-A16	120 4.724	240 9.449	Wide beam, -40 to +60 °C -40 to 140 °F	2 m 6.562 ft	P.61	
FD-AL11	100 3.937	285 11.220	Array, -55 to +80 °C -67 to 176 °F	2 III 0.002 II	P.61	
FD-E13	5 0.197	15 0.591	Cylindrical, Ultra-small dia., ø1.5 0.059, –40 to +60 °C –40 to 140 °F	1 m 3.281 ft	P.61	
FD-E23	20 0.787	70 2.756	Cylindrical, Ultra-small dia., ø3 0.118, -40 to +70 °C -40 to 158 °F	1111 0.201 1	P.61	
FD-EG30	20 0.787	70 2.756	Threaded, M3, Ultra-small dia., -40 to +70 °C -40 to 158 °F	500 mm 19.685 in	P.61	
FD-EG30S	20 0.787	70 2.756	Sleeve, Threaded, Ultra-small dia., M3, –40 to +70 $^\circ\text{C}$ –40 to 158 $^\circ\text{F}$	1 m 3.281 ft	P.62	
FD-EG31	7 0.276	25 0.984	Threaded, M3, Ultra-small dia., -20 to +60 °C -4 to 140 °F	500 mm 19.685 in	P.62	
FD-F4	Applicable pipe diameter: Outer dia. ø6 to ø26 mm ø0.236 to ø1.024 in transparent pipe [PF4 (fluorine resin) or equivalently transparent pipe, wall thick- ness 1 mm 0.039 in] Liquid absent: Beam received, Liquid present: Beam interrupted		Pipe-mountable type, Liquid level sensing, −40 to +100 °C −40 to 212 °F		P.62	
FD-F41	Applicable pipe diameter: Outer a1.024 in transparent pipe [PVC (vinyl chloride), fluorine re glass, wall thickness 1 to 3 mm Liquid absent: Beam received, L	sin, polycarbonate, acrylic,	Pipe-mountable type, Liquid level sensing, −40 to +100 °C −40 to 212 °F	- <mark>}<</mark> 2 m 6.562 ft	P.62	

Notes: 1) Note that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut.

2) The sensing range is specified for white non-glossy paper.

3) The allowable cutting range is 500 mm 19.685 in from the end that the amplifier inserted.

LASER SENSORS

PHOTO-ELECTRIC SENSORS

MICRO PHOTO-ELECTRI SENSOR

AREA SENSORS

LIGHT CURTAINS / SAFETY COMPONENTS

PRESSURE FLOW SENSORS

INDUCTIVE PROXIMITY SENSORS

PARTICULAR USE SENSORS

SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS

Reflective type

Fibers are listed in alphabetic order. Refer to p.5~ "Fiber Selection" for details of each fiber.

Model No.	Sensing range (mm in) (No	ote 1) (Note 2) / Description	Type / Ambient temperature	Fiber cable length	Dimensions
	Standard type FX-101 Long sensing range type FX-102			<mark>≫</mark> : Free-cut	Dimonologi
FD-F41Y (Note 3)	ø4 mm ø0.157 in Protective tube: Fluorine resin, le Liquid surface not contacted: Bea contacted: Beam interrupted		Contact type, Liquid level sensing, Metal-free, -40 to +70 °C -40 to 158 °F	<mark>≫</mark> 2 m 6.562 ft	P.62
FD-F8Y	ø6 mm ø0 236 in Protective tube: Fluorine resin, length 1,000 mm 39.370 in (not cuttable) Liquid surface not contacted: Beam received, Liquid surface contacted: Beam interrupted		Contact type, Liquid level sensing, -40 to +125 °C -40 to 257 °F	<mark>े</mark> ≺ 2 m 6.562 ft (Note 6)	P.62
FD-FA93	Applicable pipe diameter: Outer dia transparent pipe (When used with the tying bands: I [PFA (fluorine resin), including tran Liquid absent: Beam received, Liquid	ø8 to ø80 mm ø0.315 to ø3.150 in) islucent]	Pipe-mountable type, Liquid sensing, -40 to +70 °C -40 to 158 °F	<mark>≫</mark> 2 m 6.562 ft	P.62
FD-H13-FM2	100 3.937	280 11.024	Heat-resistant, Threaded, -60 to +130 °C -76 to 266 °F		P.63
FD-H18-L31	0 to 10 0 to 0.394	0 to 25 0 to 0.984	Heat-resistant, Glass substrate detection convergent reflective, -60 to +180 °C -76 to 356 °F		P.63
FD-H20-21	90 3.543	280 11.024	Heat-resistant, Threaded, -60 to +200 °C -76 to 392 °F	1 m 3.281 ft	P.63
FD-H20-M1	120 4.724	300 11.811	Heat-resistant, Threaded, -60 to +200 °C -76 to 392 °F	1110.2011	P.63
FD-H25-L43 (Note 4)	4 to 16 0.157 to 0.630	4 to 23 0.157 to 0.906	Heat-resistant, Glass substrate detection convergent reflective, -20 to +250 °C -4 to 482 °F (Ordinary temp. side:-20 to +70 °C -4 to 158 °F)	2 m 0.042 ft	P.63
FD-H25-L45 (Note 4)	7 to 35 0.276 to 1.378	7 to 38 0.276 to 1.496	Heat-resistant, Glass substrate detection convergent reflective, -20 to +250 °C -4 to 482 °F (Ordinary temp. side:-20 to +70 °C -4 to 158 °F)	3 m 9.843 ft	P.63
FD-H30-KZ1V-S (Note 4, 5)	25 to 80 0.984 to 3.150	10 to 220 0.394 to 8.661	Vacuum-resistant, Reflective, −30 to +300 °C −22 to 572 °F	1 m 3.281 ft	P.64
FD-H30-L32	2 to 9 0.079 to 0.354	0 to 17 0 to 0.669	Heat-resistant, Glass substrate detection convergent reflective, -60 to +300 °C -76 to 572 °F	2 m 6.562 ft	P.64
FD-H30-L32V-S (Note 4, 5)	2.5 to 6.5 0.098 to 0.256	0 to11 0 to 0.433	Vacuum-resistant, Convergent reflective, -30 to +300 °C -22 to 572 °F	3 m 9.843 ft	P.64
FD-H35-20S	85 3.346	200 7.874	Heat-resistant, Threaded, -60 to +350 °C -76 to 662 °F	1 m 3.281 ft	P.64
FD-H35-M2	75 2.953 280 11.024 ø4 mm ø0.157 in		Heat-resistant, Threaded, -60 to +350 °C -76 to 662 °F	2 m 6.562 ft	P.64
FD-H35-M2S6			Heat-resistant, Threaded, -60 to +350 °C -76 to 662 °F	2 11 0.302 1	P.64
FD-HF40Y (Note 3)			Contact type, Liquid level sensing, Metal-free, -40 to +105 °C -40 to 221 °F	≥ 2 m 6.562 ft	P.64
FD-L10 (Note 4)	0 to 4.5 0 to 0.177	0 to 5.5 0 to 0.217	Glass substrate detection, -40 to +60 °C -40 to 140 °F		P.65
FD-L11 (Note 4)	0 to 8 0 to 0.315	0 to 9 0 to 0.354	Glass substrate detection, -40 to +60 °C -40 to 140 °F		P.65
FD-L12W (Note 4)	1 to 4.5 0.039 to 0.177	0.5 to 7 0.020 to 0.276	Ultla-small, -40 to +60 °C -40 to 140 °F	<mark>≫</mark> 1 m 3.281 ft	P.65
FD-L20H	5 to 15 0.197 to 0.591	1 to 30 0.039 to 1.181	General purpose, -40 to +70 °C -40 to 158 °F		P.65
FD-L21 (Note 4)	3 to 15 0.118 to 0.591	1.5 to 16 0.059 to 0.630	Glass substrate detection, -40 to +60 °C -40 to 140 °F	≥ 2 m 6.562 ft	P.65
FD-L21W (Note 4)	7 to 12 0.276 to 0.472	3 to 14 0.118 to 0.551	Glass substrate detection, -40 to +60 °C -40 to 140 °F		P.65
FD-L22A (Note 4)	0 to 19 0 to 0.748	0 to 25 0 to 0.984	Glass substrate detection, 0 to +70 °C 32 to 158 °F		P.65
FD-L23 (Note 4)	0 to 28 0 to 1.102	0 to 30 0 to 1.181	Glass substrate detection, -20 to +70 °C -4 to 158 °F		P.65
FD-L30A (Note 4)	0 to 40 0 to 1.575	0 to 50 0 to 1.969	Glass substrate detection, 0 to +70 °C 32 to 158 °F	<mark>≫</mark> 3 m 9.843 ft	P.65
FD-L31A (Note 4)	5 to 30 0.197 to 1.181	4 to 33 0.157 to 1.299	Glass substrate detection, 0 to +70 °C 32 to 158 °F		P.65
FD-L32H (Note 4)	16 to 30 0.630 to 1.181	0 to 50 0 to 1.969	Glass substrate detection, -40 to +60 °C -40 to 140 °F	≯ 4 m 13.123 ft	P.66

Notes: 1) Note that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut.

2) The sensing range of reflective type is the value for white non-glossy paper (as for FD-H30-L32 and FD-H18-L31 50 × 50 mm 1.969 × 1.969 in glass substrate).
 3) Liquid inflow prevention joint, protective tube extension joint, fiber mounting joint are available. Please refer to p.38 for details.

4) The sensing range is specified for transparent glass 100 × 100 × 10.7 mm 3.937 × 3.937 × 10.028 in (FD-L32H: R edge, FD-L21 and FD-L21W: t2 mm t0.079 in) [FD-L10: silicon wafers 100 × 100 mm 3.937 × 3.937 in].

5) Sold as a set comprising vacuum type fiber + photo-terminal (FV-BR1) + fiber at atmospheric side (FT-J8).

6) The allowable cutting range is 1,000 mm 39.370 in from the end that is inserted to the amplifier.

Selection Guide Fibers

FX-500 FX-100 FX-300 FX-410 FX-311

FX-301-F7/ FX-301-F

128

LASER SENSORS

LIST OF FIBERS

Reflective type



Model No.	Sensing range (mm	in) (Note 1) (Note 2)	Type / Ambient temperature	Fiber cable length	Dimensions	
Model No.	Standard type FX-101	Long sensing range type FX-102	Type / Ambient temperature	rengin <mark> ≫</mark> : Free-cut	Dimensions	
FD-R31G	45 1.772	150 5.906	Square head, M3, –55 to +80 °C –67 to 176 °F	≥ 2 m 6.562 ft	P.66	
FD-R32EG	20 0.787	68 2.677	Square head, M3, -40 to +70 °C -40 to 158 °F		P.66	
FD-R33EG	7 0.276	22 0.866	Square head, M3, -20 to +60 °C -4 to 140 °F	500 mm 19.685 in	P.66	
FD-R34EG	17 0.669	60 2.362	Square head, M3, -40 to +70 °C -40 to 158 °F		P.66	
FD-R41	60 2.362	170 6.693	Square head, M4, -55 to +80 °C -67 to 176 °F		P.66	
FD-R60	110 4.331	240 9.449	Threaded, M6, Elbow, –55 to +80 $^\circ\text{C}$ –67 to 176 $^\circ\text{F}$	≫ 2 m 6.562 ft	P.66	
FD-R61Y	85 3.346	185 7.283	Oil-resistant, Square head, M6, Cable-proection type, -55 to +80 °C -67 to 176 °F		P.66	
FD-S21	25 0.984	70 2.756	Cylindrical, ø1.5 0.059, -55 to +80 °C -67 to 176 °F	1 m 3.281 ft	P.66	
FD-S30	45 1.772	155 6.102	Super quality, Cylindrical, ø3 0.118, -55 to +80 °C -67 to 176 °F	2 m 6.562 ft	P.67	
FD-S31	35 1.378	140 5.512	Cylindrical, ø3 0.118, -55 to +80 °C -67 to 176 °F	-	P.67	
FD-S32	120 4.724	345 13.583	Cylindrical, ø3 0.118, -55 to +80 °C -67 to 176 °F		P.67	
FD-S32W	80 3.150	230 9.055	Cylindrical, ø3 0.118, -40 to +60 °C -40 to 140 °F	2 III 0.302 II	P.67	
FD-S33GW	45 1.772	140 5.512	Cylindrical, ø3 0.118, –40 to +60 $^\circ\text{C}$ –40 to 140 $^\circ\text{F}$		P.67	
FD-S60Y	140 5.512	300 11.811	Chemical-resistant, Chlindrical, Metal-free, ø5.5 0.217, -40 to +70 °C -40 to 158 °F	2 m 6.562 ft (Note 3)	P.67	
FD-V30	25 0.984	75 2.953	Sleeve, Cylindrical, Side-view, ø3 0.118, -55 to +80 °C -67 to 176 °F		P.67	
FD-V30W	6 0.236	20 0.787	Sleeve, Cylindrical, Side-view, ø3 0.118, -40 to +60 °C -40 to 140 °F	<mark>≫</mark> 2 m 6.562 ft	P.67	
FD-V50	40 1.575	100 3.937	Sleeve, Cylindrical, Side-view, ø5 0.197, -55 to +80 °C -67 to 176 °F		P.68	
FD-Z20HBW	2 to 30 0.079 to 1.181	1 to 90 0.039 to 3.543	Flat with boss, -40 to +60 °C -40 to 140 °F	≫ 1 m 3.281 ft	P.68	
FD-Z20W	2 to 32 0.079 to 1.260	1 to 80 0.039 to 3.150	Flat with boss, -40 to +60 °C -40 to 140 °F		P.68	
FD-Z40HBW	1 to 90 0.039 to 3.543	0.5 to 240 0.020 to 9.449	Flat with boss, -40 to +60 °C -40 to 140 °F		P.68	
FD-Z40W	1 to 74 0.039 to 2.913	200 7.874	Flat with boss, -40 to +60 °C -40 to 140 °F	🄀 2 m 6.562 ft	P.68	
FD-Z50HW	10 to 200 0.394 to 7.874	10 to 530 0.394 to 20.866	Narrow Beam, Long range, -40 to +60 °C -40 to 140 °F		P.68	

Notes: 1) Note that the sensing range of the free-cut type fiber may be reduced by 20 % max. depending upon how the fiber is cut.

The sensing range is specified for white non-glossy paper.
 The allowable cutting range is 500 mm 19.685 in from the end that the amplifier inserted.

Sensing range when FR-Z50HW is used in combination with a reflector (optional)

Reflector	Sensing range (mm in)				
Model No.	Standard type FX-101	Long sensing range type FX-102			
RF-230	100 to 2,400 3.937 to 94.488	100 to 5,000 3.937 to 196.850			
RF-220	100 to 1,300 3.937 to 51.181	100 to 2,600 3.937 to 102.362			
RF-210	100 to 980 3.937 to 38.583	100 to 1,300 3.937 to 51.181			

Note: The sensing range is the possible setting range for the reflector. The fiber can detect an object less than 100 mm 3.937 in. However, note that if there are any white or highly-reflective surfaces near the fiber head, reflected incident light may affect the fiber head. If this occurs, adjust the threshold value of the amplifier unit before use.

Selection Guide
Fibers
Fiber Amplifiers
FX-500

FX-300

FX-410 FX-311 FX-301-F7/ FX-301-F

UV CURING SYSTEMS

FIBER OPTIONS

LASER SENSORS

FX-311

FX-301-F7/ FX-301-F

Lens (For thru-beam type fiber)

SENSORS	Lens (Fo	r thru-be	eam type fiber)									
PHOTO- ELECTRIC	Designation	Model No.		Description								
ELECTRIC SENSORS MICRO					Sensing range (mr	n in) [Lens on both side	s]					
PHOTO- ELECTRIC SENSORS					Fiber	FX-101	FX-102□					
					FT-43	2,400 94.488	3,600 141.732 (Note 2)					
AREA SENSORS				Increases the sensing range by 5 times or more.	FT-42 FT-42W	3,400 133.858	3,600 141.732 (Note 2)					
LIGHT CURTAINS / SAFETY COMPONENTS			1		FT-45X	1,600 62.992 (Note 2)	1,600 62.992 (Note 2)					
COMPONENTS PRESSURE /	Expansion lens	FX-LE1	E E E	 Ambient temperature: -60 to +350 °C 	FT-R40	3,100 122.047	3,600 141.732 (Note 2)					
FLOW SENSORS	(Note 1)		all'a	-76 to +662 °F	FT-R43	1,300 51.181	3,600 141.732 (Note 2)					
INDUCTIVE				(Note 4)	FT-H35-M2	2,000 78.740	3,500 137.795 (Note 2)					
PROXIMITY SENSORS				• Beam dia: ø3.6 mm ø0.142 in	FT-H20W-M1	1,300 51.181	1,600 62.992 (Note 2)					
PARTICULAR					FT-H20-M1	1,600 62.992 (Note 2)	1,600 62.992 (Note 2)					
SENSORS					FT-H20-J50-S FT-H20-J30-S FT-H20-J20-S	1,000 39.370	3,500 137.795 (Note 2)					
SENSOR OPTIONS					Sensing range (mr	n in) [Lens on both side	s]					
SIMPLE WIRE-SAVING UNITS					Fiber	FX-101 □	FX-102□					
WIRE-SAVING SYSTEMS				Tremendously increases the sensing range	FT-43 FT-42 FT-42W	3,600 141.732 (Note 2)	3,600 141.732 (Note 2)					
MEASURE- MENT			and the	with large diameter lenses.	FT-45X	1,600 62.992 (Note 2)	1,600 62.992 (Note 2)					
SENSORS	Super-			• Ambient temperature: -60 to +350 °C -76 to +662 °F (Note 4)	FT-R40	3,600 141.732 (Note 2)	3,600 141.732 (Note 2)					
STATIC ELECTRICITY PREVENTION	expansion lens	FX-LE2			FT-R43	3,600 141.732 (Note 2)	3,600 141.732 (Note 2)					
DEVICES	(Note 1)				FT-H35-M2	3,500 137.795 (Note 2)	3,500 137.795 (Note 2)					
LASER MARKERS				• Beam dia: ø9.8 mm ø0.386 in	FT-H20W-M1 FT-H20-M1	1,600 62.992 (Note 2)	1,600 62.992 (Note 2)					
PLC					FT-H13-FM2	3,500 137.795 (Note 2)	3,500 137.795 (Note 2)					
HUMAN MACHINE INTERFACES					FT-H20-J50-S FT-H20-J30-S FT-H20-J20-S	3,500 137.795 (Note 2)	3,500 137.795 (Note 2)					
ENEDGY					Sensing range (mm in) [Lens on both sides]							
CONSUMPTION VISUALIZATION COMPONENTS					Fiber	FX-101□	FX-102□					
FA					FT-43	510 20.079	1,400 55.118					
COMPONENTS				Beam axis is bent by 90°.	FT-42	500 19.685	1,700 66.929					
MACHINE			T		FT-42W	480 18.898	1,300 51.181					
VISION	Side-view			 Ambient temperature: -60 to +300 °C 	FT-45X	540 21.260	1,600 62.992 (Note 2)					
UV CURING SYSTEMS	lens	FX-SV1		-76 to +572 °F	FT-R43	310 12.205	930 36.614					
SYSTEMS			-Th	(Note 4)	FT-H35-M2	280 11.024	800 31.496					
				• Beam dia: ø2.8 mm ø0.110 in	FT-H20W-M1	140 5.512	400 15.748					
					FT-H20-M1	280 11.024	840 33.071					
					FT-H20-J50-S FT-H20-J30-S FT-H20-J20-S	150 5.906	410 16.142					
Selection Guide	Expansion			Sensing range increases by 4 times or	Sensing range (mr	n in) [Lens on both side	s] (Note 3)					
Fibers	lens for		- Card Street	more.	Mode	FX-101□	FX-102					
Fiber Amplifiers	vacuum	FV-LE1	A.	 Ambient temperature: 60 to +350 °C - 76 to +662 °F (Note 4) 	Fiber FT-H30-M1V-S	450 17.717	1,600 62.992					
Amplifiers	fiber (Note 1)			• Beam dia: ø3.6 mm ø0.142 in	1		1,000 02.332					
EV 500	Vacuum-				Sensing range (mr	n in) [Lens on both side	s] (Note 3)					
FX-500	resistant		P. D. C.	Beam axis is bent by 90°. • Ambient temperature:	Fiber	FX-101	FX-102□					
FX-100	side-view	FV-SV2	S DED	-60 to +300 °C -76 to +572 °F (Note 4)	FT-H30-M1V-S	450 17.717	1,600 62.992					
FX-300	(Note 1)		Clean	• Beam dia: ø3.7 mm ø0.146 in			,					
FX-410	Notes: 1) Be	careful sur	re to use it only after	r you have adjusted it sufficiently when installin	ng the thru-beam type	e fiber equipped with the e	expansion lens, as the					

Notes: 1) Be careful sure to use it only after you have adjusted it sufficiently when installing the thru-beam type fiber equipped with the expansion lens, as the beam envelope becomes narrow and alignment is difficult.

2) The fiber cable length practically limits the sensing range.
3) The fiber cable length for the FT-H30-M1V-S is 1 m 3.28 ft. The sensing ranges in FX-102 are specified considering the length of the FT-J8 atmospheric side fiber.

4) Refer to "LIST OF FIBERS (p.124~)" for the ambient temperature of fibers to be used in combination.

FIBER OPTIONS

Refer to p.69~ for details of lens dimensions.

Len

ens (For reflective type fiber)									
Designation		Model No.	Description						
	Pinpoint spot lens	FX-MR1		Pinpoint spot of Ø0.5 mm Ø0.020 in. Enables detection of minute objects or small marks. • Distance to focal point: 6 ± 1 mm 0.236 ± 0.039 in • Applicable fibers: FD-42G, FD-42GW • Ambient temperature: -40 to +70 °C -40 to +158 °F (Note)					
					Sensing range f	or FX-100 ser	ies		
			Screw-in depth	mm $\emptyset 0.028$ to $\emptyset 0.079$ in according to how much the fiber is screwed in.	Screw-in depth	Distance to focal point	Spot diameter		
	Zoom lens	FX-MR2	Distance to	 Applicable fibers: FD-42G, FD-42GW Ambient temperature: -40 to +70 °C 	7 mm 0.276 in	18.5 mm 0.728 in approx.	ø0.7 mm ø0.028 in		
			focal point	-40 to +158 °F (Note)	12 mm 0.472 in	27 mm 1.063 in approx.	ø1.2 mm ø0.047 in		
			→i→ Spot diameter	Accessory: MS-EX3 (mounting bracket)	14 mm 0.551 in	43 mm 1.693 in approx.	ø2.0 mm ø0.079 in		
				Extremely fine spot of Ø0.15 mm Ø0.006 in	Sensing range for FX-100 series				
	Finest spot lens		- Distance to focal point Spot diameter	approx. achieved. • Applicable fibers: FD-EG31, FD-EG30, FD-42G, FD-42GW, FD-32G, FD-32GX • Ambient temperature: -40 to +70 °C	Fiber model No.	Distance to focal point	Spot diameter		
oer					FD-EG31	7.5 ±0.5 mm 0.295 in ±0.020 in	ø0.15 mm ø0.006 in approx.		
oe fik		FX-MR3			FD-EG30	7.5 ±0.5 mm 0.295 in ±0.020 in	ø0.3 mm ø0.012 in approx.		
For reflective type fiber				-40 to +158 °F (Note)	FD-42G/42GW FD-32G/32GX	7.5 ±0.5 mm 0.295 in ±0.020 in	ø0.5 mm ø0.020 in approx.		
. refle				Extremely fine spot of ø0.1 mm ø0.004 in approx. achieved. • Applicable fibers: FD-EG31, FD-EG30, FD-42G, FD-42GW,	Sensing range f	or FX-100 ser	ies		
For					Fiber model No.	Distance to focal point	Spot diameter		
	Finest spot				FD-EG31	7 ±0.5 mm 0.276 in ±0.020 in	ø0.1 mm ø0.004 in approx.		
	lens	FX-MR6		FD-32G, FD-32GX • Ambient temperature: −20 to +60 °C	FD-EG30	7 ±0.5 mm 0.276 in ±0.020 in	ø0.2 mm ø0.008 in approx.		
				-4 to +140 °F (Note)	FD-42G/42GW FD-32G/32GX	7 ±0.5 mm 0.276 in ±0.020 in	ø0.4 mm ø0.016 in approx.		
			Screw-in	FX-MR2 is converted into a side-view type and	Sensing range f	or FX-100 ser	ies		
	Zoom lens		ter depth	can be mounted in a very small space.	Fiber model No.				
	∠oom iens /side-view∖	FX-MR5		 Applicable fibers: FD-42G, FD-42GW Ambient temperature: -40 to +70 °C 		13 mm 0.512 in approx.			
	(type		Distance to focal point	-40 to +158 °F (Note)	10 mm 0.394 in	15 mm 0.591 in approx.			
			↓ → I ← Spot diameter			30 mm 1.181 in approx.			
			Spot diameter						

Ł Note: Refer to p.126 for the ambient temperature of fibers to be used in combination.

Lens (For square head M3 reflective fiber)

		Spot diamotor	Distance to	Lens		Fiber		
	Туре	Spot diameter (mm in)(Note)	focal point (mm in)(Note)	Shape (mm in)	Model No.	Shape	Emitting fiber core (mm in)	Model No.
	Finest spot lens	ø0.1 ø0.004 approx.			FX-MR7		ø0.125 ø0.005	FD-R33EG
Der							ø0.125 ø0.005	FD-EG31
ive fit		ø0.15 ø0.006 approx.					ø0.175 ø0.007	FD-R34EG
eflecti		Ø0.2 Ø0.008 approx. 7 ± 0.5					ø0.25 ø0.010	FD-R32EG
M3 re			7 ± 0.5				ø0.25 ø0.010	FD-EG30
For Square head M3 reflective fiber			0.276 ± 0.020				ø0.5 ø0.020	FD-R31G
							ø0.5 ø0.020	FD-32G
		ø0.4 ø0.016 approx.					ø0.5 ø0.020	FD-32GX
							ø0.5 ø0.020	FD-42G
							ø0.5 ø0.020	FD-42GW

		Spot diameter	Sensing range	Lens		Applicable fibers	
Туре		(mm in)(Note)	(mm in)(Note)			Emitting fiber core (mm in)	Model No.
	su	Ø0.4 to Ø2.0 Ø0.016 to Ø0.079 approx.		Ø5 Ø0. <u>197</u> ↑	FX-MR8	ø0.125 ø0.005	FD-R33EG, FD-EG31
M3	ler	Ø0.4 to Ø2.2 Ø0.016 to Ø0.087 approx.	10 to 30			ø0.175 ø0.007	FD-R34EG
ber	Dom	Ø0.5 to Ø2.5 Ø0.020 to Ø0.098 approx.	0.394 to1.181			ø0.25 ø0.010	FD-R32EG, FD-EG30
e he /e fi	Ň	Ø0.8 to Ø3.5 Ø0.031 to Ø0.138 approx.				ø0.5 ø0.020	FD-R31G, FD-32G, FD-32GX, FD-42G, FD-42GW
uare	S			10		ø0.125 ø0.005	FD-R33EG, FD-EG31
For Square head M3 reflective fiber	allel lens	ad 0 a0 157 approv	0 to 30	ø5 ø0.197	FX-MR9	ø0.175 ø0.007	FD-R34EG
	Para	ø4.0 ø0.157 approx.	0 to 1.181			ø0.25 ø0.010	FD-R32EG, FD-EG30
				Ť		ø0.5 ø0.020	FD-R31G, FD-32G, FD-32GX, FD-42G, FD-42GW

Note: Spot diameter, distance to focal point and sensing range are specified for FX-100 series.

LASER SENSORS

PHOTO-ELECTRIC SENSORS

MICRO PHOTO-ELECTRIC SENSORS

AREA SENSORS

LIGHT CURTAINS / SAFETY COMPONENTS PRESSURE / FLOW SENSORS

INDUCTIVE PROXIMITY SENSORS

PARTICULAR USE SENSORS

SENSOR OPTIONS

SIMPLE WIRE-SAVING UNITS

WIRE-SAVING SYSTEMS MEASURE-MENT SENSORS

STATIC ELECTRICITY PREVENTION DEVICES

LASER MARKERS

HUMAN MACHINE INTERFACES

ENERGY CONSUMPTION VISUALIZATION COMPONENTS

FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

Selection Guide Fibers

FX-500

FX-300 FX-410 FX-311 FX-301-F7/ FX-301-F

PLC

SPECIFICATIONS

\swarrow		Turne	Standa	rd type	Long sensing range type				
	\sim	Туре		Cable set		Cable set			
	Ś	NPN output	FX-101(-Z) (Note 5)	FX-101-CC2	FX-102(-Z) (Note 5)	FX-102-CC2			
Iten	Model No	PNP output	FX-101P(-Z) (Note 5)	FX-101P-CC2	FX-102P(-Z) (Note 5)	FX-102P-CC2			
Sup	ply voltage		12 to 24 V DC ±10 % Ripple P-P 10 % or less						
Pow	ver consump	otion	Normal operation: 720 mW or less (Current consumption 30 mA or less at 24 V supply voltage) ECO mode: 600 mW or less (Current consumption 25 mA or less at 24 V supply voltage)						
Output			<npn output="" type=""> NPN open-collector transistor • Maximum sink current: 100 mA • Applied voltage: 30 V DC or less (between output and 0 V) • Residual voltage: 1.5 V or less (at 100 mA sink current) • Maximum source current: 100 mA • Applied voltage: 30 V DC or less (between output and +V) • Residual voltage: 1.5 V or less (at 100 mA source current)</npn>						
Output operation			Selectable either Light-ON or Dark-ON, at SET mode						
	Short-circu	uit protection		Incor	porated				
Exte	External input		<npn output="" type=""> NPN non-contact input • Signal condition High: +8 V to +V DC or C Low: 0 to +2 V DC (Source current 0.5 mA o • Input impedance: 10 kΩ a</npn>	r less)	<pnp output="" type=""> PNP non-contact input • Signal condition High: +4 V to +V DC (Sink current 0.5 to 3 mA) Low: 0 to +0.6 V DC or Open • Input impedance: 10 kΩ approx.</pnp>				
Res	Response time		Emission frequency 0: 250 µs Emission frequency 1: 450 µs Emission frequency 2: 500 µs Emission frequency 3: 600 µs	or less	Emission frequency 1: 2.5 ms or less (factory default setting) Emission frequency 2: 2.8 ms or less Emission frequency 3: 3.2 ms or less Emission frequency 4: 5.0 ms or less				
Sensitivity setting		ng	2-point teaching / Limit teaching / Full-auto teaching						
Operation indicator		ator	Orange LED (lights up when the output is ON)						
Digit	tal display		4 digits (green) + 4 digits (red) LCD display						
Fine	Fine sensitivity adjustment function		Incorporated						
Time	er function		ON-delay / OFF-delay timer, switchable either effective or ineffective [Timer period: 1 ms, 5 ms, 10 ms, 20 ms, 40 ms, 50 ms, 100 ms, 500 ms, 1,000 ms]						
Emis	ssion amoun	t setting function		3-level + Auto setting (from	production in December 2007)				
Inter func	rference pre tion	evention	Incorporated Emission frequency sel (Functions at emission		Incorporated Emission frequency selection method (Note 2) (Functions at emission frequency 1, 2, 3 or 4)				
istance	Ambient te	emperature	-10 to +55 °C +14 to +131 °F (If 4 to 7 units are mounted close together: -10 to +50 °C +14 to +122 °F, if 8 to 16 units are mounted close together -10 to +45 °C +14 to +113 °F) (No dew condensation or icing allowed), Storage: -20 to +70 °C -4 to +158 °F						
esista	Ambient h			· · · · · · · · · · · · · · · · · · ·	orage: 35 to 85 % RH				
_	Ambient ill	luminance		Incandescent light: 3,000	tx at the light-receiving face				
Environmental	Voltage wi	ithstandability	1,000 V AC for	one min. between all supply terr	minals connected together and enclosure (Note 3)				
ronn	Insulation	resistance	20 MΩ, or more, with 25	50 V DC megger between all su	upply terminals connected together and enclosure (Note 3)				
Invi	Vibration r	resistance	10 to 150 Hz fr	equency, 0.75 mm 0.030 in amp	litude in X, Y and Z directions for	r two hours each			
Ш Shock resistance		istance	98 m/s	² acceleration (10 G approx.) in	X, Y and Z directions for five time	es each			
Emitting element (modulated)		nt (modulated)	Red LED (Peak emission wavelength: 643 nm 0.025 mil)						
Material			Enclosure: Polycarbonate, Key switch: Polycarbonate, Fiber lock lever: PBT						
Connecting method		thod	Connector (Note 4)						
Cable length			Total	length up to 100 m 328.084 ft is	possible with 0.3 mm ² , or more,	cable.			
Wei	ght		Net weight: 15 g approx. Gross weight: 35 g approx.	Net weight: 15 g approx. Gross weight: 75 g approx.	Net weight: 15 g approx. Gross weight: 35 g approx.	Net weight: 15 g approx. Gross weight: 75 g approx.			
Accessory			FC-FX-1 (Protection cover): 1 pc. (Note 6)	FC-FX-1 (Protection cover): 1 pc. (Note 6) CN-14A-C2 (Connector attached cable, 2 m 6.582 ft long): 1 pc.	FC-FX-1 (Protection cover): 1 pc. (Note 6)	FC-FX-1 (Protection cover): 1 pc. (Note CN-14A-C2 (Connector attached cable, 2 m 6.562 ft long): 1			

Notes: 1) Where measurement conditions have not been specified precisely, the conditions used were an ambient temperature of +23 °C +73.4 °F. 2) When using the interference prevention function, set the emission frequencies for the amplifiers to be covered by the interference prevention function to different frequency values.

However, the interference prevention function does not operate at emission frequency 0 (factory default setting) for the **FX-101(P)(-Z)** / **FX-101(P)-CC2**. 3) The voltage withstandability and the insulation resistance values given in the above table are for the amplifier only.

4) Connector attached cable CN-14A-C2 is not attached to the models that have no "-CC2" at the end of the model Nos.

Make sure to use the optional connector attached cable CN-14A(-R)-C or the connector CN-14A, or a connector manufactured by J.S.T. Mfg., Ltd. (contact: SPHD-001T-P0.5, housing: PAP-04V-S).

5) Model Nos. having the suffix "-Z" are M8 plug-in connector type. Make sure to use the optional M8 attached connector cable CN-24A-C ...

6) Protection cover FC-FX-1 has been attached from production in July, 2011.

Selection Guide Fibers

FX-500 FX-100 FX-300 FX-410 FX-311 FX-301-F7/ FX-301-F7/

I/O CIRCUIT AND WIRING DIAGRAMS





100 .937

50 .969

60 2 362 40 20

Left-

Fiber head

©|^{Up} Down

► Up

FX-101

- Center

Operating point { (mm in)

50

40 1.575

20

Down

Fiber

Right

₿

Right

FX-101

- Center

Operating point { (mm in)

50

٥

40 1.575

20

Left-

100 3.937

50

0

60

40

Down -

20 Ó 20

- Center

Operating point { (mm in)

969

1L ÷ Fihe

Right

Ē head

Right

20 0.787 40

Center

Operating point { (mm in)

L Fiber head

Down

l I Up

40

→ Up

SENSING CHARACTERISTICS (TYPICAL)



SENSING CHARACTERISTICS (TYPICAL)

Center

Operating point { (mm in)

Right

Selection Guide

Fibers

EX-500

FX-100

FX-300

FX-410

FX-311 FX-301-F7/ FX-301-F

PRECAUTIONS FOR PROPER USE

- Never use this product as a sensing device for personnel protection.
- In case of using sensing devices for personnel protection, use products which meet laws and standards, such as OSHA,
- ANSI or IEC etc., for personnel protection applicable in each region or country.

Using in combination with the FX-300 / FX-410 series

The FX-100 series does not use the horizontal connectors that are used with the FX-300 / FX-410 series. Please note that horizontal connection cannot be performed using a connector attached cable. In addition, the optical communication function is not equipped on the FX-100 series, so it is unable to perform interference prevention for use with the FX-300 / FX-410 series. If using the FX-100 series together with the FX-300 / FX-410 series side-by-side, please set the same models together in groups.

Mounting

<When using a DIN rail>

How to mount the amplifier

- Fit the rear part of the mounting section of the amplifier on a 35 mm 1.378 in width DIN rail.
- ② Press down the rear part of the mounting section of the unit on the 35 mm 1.378 in width DIN rail and fit the front part of the mounting section to the DIN rail.



35 mm 1.378 in width DIN rail

How to remove the amplifier

Push the amplifier forward.
 Lift up the front part of the amplifier to remove it.



Note: Take care that if the front part is lifted without pushing the amplifier forward, the hook on the rear portion of the mounting section is likely to break.

<When using screws with washers>

 Use M3 screws with washers for mounting. The tightening torque should be 0.5 N·m or less.



Refer to General precautions, and to the "Operation Guide" on our website for details pertaining to operating instructions for the amplifier.

Wiring

- Make sure that the power supply is OFF while adding or removing the amplifiers.
- Note that if a voltage exceeding the reted range is applied, or if an AC power supply is directly connected, the product may get burnt or damaged.
- Note that short-circuit of the load or wrong wiring may burn or damage the product.
- Do not run the wires together with high-voltage lines or power lines, or put them in the same raceway. This can cause malfunction due to induction.
- Verify that the supply voltage variation is within the rating.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- In case noise generating equipment (switching regulator, inverter motor, etc.) is used in the vicinity of this product, connect the frame ground (F.G.) terminal of the equipment to an actual ground.
- Make sure to use the quick-connection cable (optional) for the connection of the controller.

Extension up to total 100 m 328.084 ft is possible with 0.3 mm² or more, cable. However, in order to reduce noise, make the wiring as short as possible.

Part description



Setting mode

• Setting mode appears after the MODE key is pressed for 2 sec. in RUN mode.

Setting item	Factory setting	Description		
Teaching mode	<u>ERch</u>	Threshold value can be set in 2-point teaching, limit teaching, or full-auto teaching.		
Output operation setting	L_d_d_on [Dark-ON]	Light-ON or Dark-ON can be set.		
Timer operation setting	<u>dEL วี กอก</u> [Without timer]	Without timer, ON delay timer, or OFF delay timer can be set.		
Timer delays setting	[ON-delay timer: 10 ms] [OFF-delay timer: 10 ms]	 When setting ON delay timer or OFF delay timer in the timer operation setting mode, timer delays can be set. When timer is not set, this mode is not displayed. 		
Emission amount setting	Pct/ ///// * [Level 3]	In case incident light intensity is saturated, emission amount can be reduced.		
Emission frequency setting	FX-101 $F_{F} \notin q = F_{-}$ (0 (Response time: 250 µs or less) FX-102 $F_{F} \notin q = F_{-}$ [1 (Response time: 2.5 ms or less)	When using the fiber heads in parallel, interference can be prevented by setting different emission frequency. However, when emission frequency 0 is set, interference cannot be prevented. Response time corresponds to emission frequency.		
* Indicated as " Pctt off " before production in November 2007.				

IBER ENSORS

LASER SENSORS

MEASURE-

MENT SENSORS

STATIC ELECTRICITY PREVENTION

LASER MARKERS

DEVICES

PLC

HUMAN

MACHINE INTERFACES

FA COMPONENTS

MACHINE VISION SYSTEMS

UV CURING SYSTEMS

PRECAUTIONS FOR PROPER USE

PRO mode

 PRO mode appears after the MODE key is pressed for 4 sec. in RUN mode.

sec. In	RUN mode.	
Setting item	Factory setting	Description
Shift setting	[Shift amount 15 %]	Shift amount can be selected from 0 to 80 % in the limit teaching. Select 0 % when it is desired to set the present incident light intensity as a threshold value.
External input setting	[n ^p <u>t</u> <mark>- o</mark> F] [Emission halt]	External input can be selected from emission halt, limit teaching [+], limit teaching [-], full-auto teaching, ECO (Note 1), 2-point teaching or emission amount test. When setting the incident light intensity test " $\underbrace{\cline{E5}}_{\cline{E5}}$ ", output turns ON / OFF every 100ms when the rate of incident light intensity and threshold value is less than half of the set shift amount (for example, when the rate of incident light intensity and threshold value is within ±10 % for 20 % of shift amount) at external input.
Threshold value-storing setting mode (Note 2)	<mark>b-uP oFF</mark> [OFF]	Threshold value set at the limit teaching, full-auto teaching or 2-point teaching by external input is stored. When selecting Auto in the emission amount setting mode, the set emission amount level is also stored.
Threshold value follow-up cycle setting (Note 3)	[<u>[ycl off</u> [Off]	When incident light intensity exceeds threshold value, this mode can change the threshold value with each set cycle depending on variations of the incident light intensity. The follow-up shift amount is same as the one set in the shift setting mode. However, the threshold value is not stored.
GETA function setting (Note 4, 5)	[] [OFF]	Variations can be reduced by correcting the present incident light intensity in each amplifier to a target value. Target value to offset incident light intensity can be selected from 0 to 2,000 by 100 unit each. For example, if the target value is set to 2,000 when the incident light intensity is 1,500, the incident light intensity becomes 2,000.
ECO setting	Eca aff [OFF]	It is possible to light up / turn off the digital display. When ECO setting mode is ON, the display turns off in 20 sec. approx. in RUN mode. To light up the display again, press any key for 2 sec. or more.
Digital display inversion setting	Corn OFF	Digital display can be inverted.
Threshold value margin setting	R <u>irt off</u> [OFF]	Margin for threshold value to the present incident light intensity can be checked. When there is no margin, it is possible to make the digital display blink. aFF : Set to "OFF": does not function Grfn : Green blinks. rEd : Red blinks. RLt : Red and green blink. In-t : When conducting limit teaching or 2-point teaching by external input, in case the rate of reference incident light intensity and threshold value after teaching is 200% or more, or in case it is less than half of the shift amount, output turns ON / OFF every 100 ms. (Note 6)
Setting copy		The settings of the master side amplifier can be copied to the slave side amplifier. For details, refer to "Setting copy function ".
Reset	-5 <u>55 ng</u> [NO]	Returns to default settings (factory settings.)

- Notes: 1) When ECO is selected at the external input setting mode, key operation on the main body is invalid during external input.
 - operation on the main body is invalid during external input.
 This mode is not indicated unless any of " <u>μ</u><u>μ</u><u>μ</u>", "<u>μ</u><u>μ</u><u>μ</u>", "<u>μ</u><u>μ</u><u>μ</u>", "<u>μ</u><u>μ</u><u>μ</u>" or " <u>2</u>-*P*<u>μ</u>" is set at the external input setting mode. (Incorporated from production in December 2007.)
 - (interpotential form podductor in December 2007.)
 3) If the incident light intensity becomes "300" or less, the follow-up operation stops. In that condition, threshold value [digital display (green)] blinks. This function can be used when thru-beam type or retroreflective type fiber is applied to this product. If reflective type fiber is applied to this product. If reflective type fiber is applied to the used depending on use conditions.
 - is applied, the function cannot be used depending on use conditions.
 4) If MODE key is pressed in RUN mode when GETA function is used, the incident light intensity before setting GETA function is displayed on the red digital display for 2 sec. approx.
 - 5) When GETA function is used in saturation of incident light intensity (4,000 or more,) " HRr d" is indicated on the red digital display. Correction value is up to 4,000.
 - 6) This mode does not operate unless any of "Ltcp", "Ltc-" or "2-Pt" is set at the external input setting mode. (Incorporated from production in December 2007.)

Refer to General precautions, and to the "Operation Guide" on our website for details pertaining to operating instructions for the amplifier.

Setting copy function

- This can copy the settings of the master side amplifier to the slave side amplifier.
- Be sure to use the setting copy function between the identical models (Between **FX-101**□ models or **FX-102**□ models).

This function cannot be used between different models.

- Only one sensor can be connected on slave side with a master side sensor for the setting copy function.
- Threshold value, output operation setting, timer operation setting, timer setting, light-emitting amount setting, shift setting, external input setting, threshold value margin setting, ECO setting, digital display inversion setting, and threshold value margin setting can be copied.

<Setting procedures>

- ① Set the setting copy mode of the master side amplifier to "Copy sending ON", and press the MODE key so that " [of red " is shown on the digital display and the sensor is in copy ready state. For the setting method, refer to "Operation guide".
- Turn off the master side amplifier.
- ③ Connect the master side amplifier with the slave side amplifier as shown below.



- ④ Turn on the master side amplifier and the slave side amplifier at the same time. (Note)
- (5) " [opy]" is shown on the green digital display of the master side amplifier and 4-digit code is shown on the red digital display of it, then the copying starts. During copy communication, " [opy]" is shown on the green digital display of the slave side amplifier, and the ongoing copy communication indicator (" 1"→" 11"→" 11"→" 11"→" 11"→" 111"→" 111"→" 111"→" 111"→" 111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→" 1111"→

the red digital display.

- (6) When the copying is completed, " good " is shown on the green digital display of the slave side amplifier, while the 4-digit code (the same code as the master side amplifier) is shown on the red digital display of it.
- ⑦ Turn off the power of the master side amplifier and the slave side amplifier and disconnect the wire.

* If copying the settings to another amplifier repeatedly, follow the steps 3 to 0.

Note: Take care that if the power is not turned on at the same time, the setting contents may not be copied.

<To cancel the setting copy mode of the master side amplifier>

① While the slave side amplifier is disconnected, turn on the power of the master side amplifier.

2 Press the MODE key for 2 sec. approx.



FX-311

FX-301-F7/ FX-301-F

CURING

Selection Guide Fibers

FX-500 FX-100 FX-300

FX-410

FX-311 FX-301-F7/ FX-301-F

PRECAUTIONS FOR PROPER USE

Others

- Our products have been developed / produced for industrial use only.
- Do not use during the initial transient time (0.5 sec.) after the power supply is switched on.
- Take care that the product is not directly exposed to fluorescent lamp from a rapid-starter lamp, a high frequency lighting device or sunlight etc., as it may affect the sensing performance.
- · This product is suitable for indoor use only.
- Avoid dust, dirt, and steam.
- Take care that the product does not come in contact with oil, grease, organic solvents, such as thinner, etc., strong acid or alkaline.
- This product cannot be used in an environment containing inflammable or explosive gases.
- Never disassemble or modify this product.
- EEPROM is adopted to this product. It is not possible to conduct teaching 100 thousand times or more, because of the EEPROM's lifetime.

Quick setting function

- The quick setting function makes it possible to set the content of the SET Mode (output operation, timer operation, amount of light emitted, and frequency of light emitted) simply by selecting a setting number.
- While in the RUN Mode, pressing and holding both the ON key (ⓐ) and OFF key (ⓑ) simultaneously for 2 seconds will switch to the quick setting function.

<Table of quick setting numbers>

No.	Output operation	Timer	Emission amount setting (Note)
-88-	D-ON	non	Level 3 (OFF)
-84-	D-ON	non	Level 2 (ON)
-62-	D-ON	ofd 10 ms	Level 3 (OFF)
-83-	D-ON	ofd 10 ms	Level 2 (ON)
-84-	D-ON	ofd 40 ms	Level 3 (OFF)
-85-	D-ON	ofd 40 ms	Level 2 (ON)
-86-	D-ON	ond 10 ms	Level 3 (OFF)
-87-	D-ON	ond 10 ms	Level 2 (ON)
-88-	D-ON	ond 40 ms	Level 3 (OFF)
-89-	D-ON	ond 40 ms	Level 2 (ON)
- 18-	L-ON	ond 40 ms	Level 2 (ON)
- { {-	L-ON	ond 40 ms	Level 3 (OFF)
- 12-	L-ON	ond 10 ms	Level 2 (ON)
- 13-	L-ON	ond 10 ms	Level 3 (OFF)
- 14-	L-ON	ofd 40 ms	Level 2 (ON)
- 75-	L-ON	ofd 40 ms	Level 3 (OFF)
- 16 -	L-ON	ofd 10 ms	Level 2 (ON)
- {]-	L-ON	ofd 10 ms	Level 3 (OFF)
- 18-	L-ON	non	Level 2 (ON)
- 19-	L-ON	non	Level 3 (OFF)

Note: Until production in November 2007, OFF or ON was selectable. The emission amount of Level 2 (ON) is about 40% of that of Level 3 (OFF).

Difference between previous model and upgraded one

• For upgraded ones (production in and after December 2007), "P" is marked near the beam-emitting inlet. Previous ones have no marking. Appearance and functions have been changed.



<Previous>

Refer to General precautions, and to the "Operation Guide" on our website for details pertaining to operating instructions for the amplifier.

Code setting function

- The code setting function makes it possible to set the output operation, timer operation, amount of light emitted, frequency of light emitted, ECO setting, external input, and amount of shift by selecting a code of one's choice.
- While in the RUN Mode, pressing and holding both the ON key (a) and OFF key (c) simultaneously for 4 seconds will switch to the code setting function.

<Code table>



	1st	digit		2nd digit	t	3rd digit 4th dig		
Code		_ .	Emission		ssion uency		External input	Shift
Ŭ	Output operation	Timer (Note 1)	amount setting	FX-101	FX-102	ECO		(Note 1)
			(Note 2)					
0		non		0	1		Emission halt	5 %
1		ond 10 ms	Level 3	1	2		Limit teaching [+]	10 %
8	D-ON	ond 40 ms	(OFF)	2	3	OFF	Limit teaching [-]	15 %
3		ofd 10 ms		3	4		Full-auto teaching	20 %
ч		ofd 40 ms		0	1		ECO	25 %
5		non	Level 2 (ON)	1	2		Emission halt	30 %
6		ond 10 ms		2	3		Limit teaching [+]	35 %
7	L-ON	ond 40 ms		3	4	ON	Limit teaching [-]	40 %
8		ofd 10 ms		0	1		Full-auto teaching	45 %
9		ofd 40 ms		1	2		ECO	50 %
R			Level 1	2	3	OFF	2-point teaching	
Ь				3	4	OFF	Incident light intensity test	
c				0	1		2-point teaching	
d			Auto	1	2	ON	Incident light intensity test	
ε			Auto	2	3			
F				3	4			

Notes: 1) When the present setting is out of the code setting range, "-" is shown. When "-" is selected, the set content of the digit is not changed.

2) Until production in November 2007, OFF or ON was selectable. The emission amount of Level 2 is about 40% of that of Level 3. The emission amount of Level 1 is about 20% of that of Level 3.
3) The factory setting is " [[[[[]] ".

138

DIMENSIONS (Unit: mm in)





Amplifier

Note: The protection cover has been attached from the production at July, 2011.



CN-14A-C CN-14A-R-C





Note: The protection cover has been attached from the production at July, 2011.



Connector attached cable (Optional)

CN-14A-C2 is attached FX-101(P)-CC2 / FX-102(P)-CC2

Length L

1,000 39.370

2,000 78.740

3,000 118.110

5,000 196.850

Material: Polycarbonate

Length L

Model No.

CN-14A(-R)-C1

CN-14A(-R)-C2

CN-14A(-R)-C3

CN-14A(-R)-C5

Selection Guide
Fibers
Fiber Amplifiers
FX-500

LASER MARKERS

HUMAN MACHINE INTERFACES

ENERGY CONSUMPTION VISUALIZATION COMPONENTS

FA COMPONENTS

MACHINE

VISION SYSTEMS

UV CURING SYSTEMS

PLC

FX-100
FX-300
FX-410
FX-311